Thank you for purchasing this quality product. It has been engineered for easy assembly yet constructed for durability. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the part lists below.

(03)

Please be sure to read the notes section at the bottom of the page, and follow the instruction while assembling. Thank you

ASSEMBLY INSTRUCTION RECTANGULAR TAKE OUT LEAF EXTENSION TABLE

Model: RT82 (TSE-1813-T/B)



Co	ode	Figure	Part	Qty.
(	(3)		Table Top	1
(	22		Pedestals	2
(	3		Pedestal Sides	4
(	(4)		Center Rail	1
(	<u>(5</u>		Base Legs	2
(	9		Center Leaf	1
(	97)		Mounting Plates	2

## List of hardware For 1 Set

Code	Figure	Hardware	Qty.
<b>a</b>	0	Flat Washer 16" x 22mm	12
<b>(b)</b>	0	Spring Washer 15"	12
©	9	JCBC Bolt M8 x 80mm	6
<b>(d)</b>	ſ	Allen Key M5	1
<b>e</b>		Hexagon Nut 16" x 7mm	6
<b>f</b>	\ \ \	Spanner 12.8mm	1
9	0	Flat Washer ½" x 16mm	12
h	Ø	Spring Washer 4 "	12
1	9	JCBC Bolt M6 x60mm	4
(1)	9	JCBC Bolt M6 x50mm	8
k	ſ	Allen Key M4	1

## 1 Important Notes


The Touch of a soft cloth is all the

Never use harsh chemicals or abrasive \* cleaner as they could mark or destroy

\* maintenance your wood pieces will

ever need.

- Keep all hardware parts out of reach of children.
- \* Must tighten screws periodically.With use screws will become loose.Check tightness of all screws every 6-8 weeks.
- \* Don't attempt to repair or modify parts that are broken or defective.Please contact the store immediatedly.
- Do not tighten all screw / bolt until all completly assembled



MADE IN MALAYSIA