


# Assembly Instructions

## TABLE

**CAUTION:** You must read this before you proceed.

**Please look underneath table top for hardware packs.**





**CAUTION :** This Table is NOT a TOY.





Keep your child / children at bay in the process of assembly.

For turning the Table and to prevent damage to the Table, 2 people may be needed to execute this action.

## Parts List




No.	Picture	Description	Qty
<b>A</b>		Table Top	1
<b>B</b>		Leg	4

## Hardware

Label	Picture	Description	QTY
①		Bolt (M6 x 50mm)	9
②		Washer	9
③		Spring Washer	9
④		Allen Key	2

## Assembly Preparation

### Before Beginning Assembly:



☒ Read instructions, cover to cover.



☒ Have 2 adults on hand for assembly.



☒ Do not assemble on flooring or carpet.




☒ Assemble on a clean non-marring surface (packing foam).



☒ Save all packaging until finished.


## Assembly Steps

### Overview




This Table has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Table parts, the above picture is to help you put the various parts into perspective. Please read through the instructions here below to familiarise yourself with the parts and steps before assembly.

### **Step 1**



Unpack and place all parts on a clean, non-marring surface.

### **Step 2**




Place the Table Top (A) facedown onto a clean, non-marring surface.

First, insert the Legs (B) into the mounting positions on the Table Top (A), then secure them using Washers (②), Spring Washers (③), and Bolts (①) with the Allen Key (④) as shown above.

Repeat the same process with the remaining Legs (B).

**Do not fully tighten the Bolts**

### **Step 3**



Turn the Table right side up, with assistance from your adult partner.

Exert pressure floorwards, onto the Table with both your hands.

This pressure will help the Legs and Table Top reach full alignment status.

Check for wobbles on a LEVEL surface.

If no wobbles are found proceed to tighten the Bolts in a sequential manner, until evenly secured.

When tightening the Bolts, tighten sequentially.



















Do not tighten any Bolt fully and then move on towards the next one.

If there are still wobbles after tightening, loosen the Bolts and execute the same above process.

**Your Table is ready for use.**

**This Table can only be used on a flat, level surface.**

## Care & Maintenance

-   ● Do not put hot items directly on furniture surface
-   ● Do not clean furniture with harsh cleansers or polish.
-   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
-   ● Children should not climb or jump on the furniture.
-   ● Do not write on furniture without a padded barrier to protect the surface.
-   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
-   ● Not for commercial use. For residential use only .
-   ● Stains may be removed with mild soap solution and damp cloth.
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.