ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardwre and Furniture part list for guidance.

Be sure all parts are complate, before you assemble. Pace all wooden prevent from being scratched. Follow the figure to start assembling.

- CAUTIONS: 1. Do not FULLY- TIGHTEN the nut or bolt until all nut and bolt is ready assembled.
 - 2. Do not OVER TIGHTEN the nut or bolt avoid causing damages to the thread.
 - 3. Keep all hardware parts out of reach of children.

	PART LIST			
	ITEM	DESCRIPTION	QTY	
	A	LEG	4 PCS	
	В	ROUND FRAME	1 PC	
	С	GROSS SUPPORT (UP)	1 PC	
	D	GROSS SUPPORT (DOWN)	1 PC	
	Е	CUSHION SEAT	1 PC	

	HARDWARE LIST				
ITEM	DESCRIPTION		QTY		
1	WOOD DOWEL M10 x 30mm		4 PCS		
2	JCBC SCREW M6 x 35mm	(III)	4 PCS		
3	JCBC SCREW M6 x 40mm	(6)	4 PCS		
4	SPRING WASHER M6	0	4 PCS		
5	FLAT WASHER M6 x 13mm	0	4 PCS		
6	CSK SCREW M4 x 32mm	~ammm(∳)	4 PCS		
7	ALLEN KEY M4		1 PC		

