
Assembly Instructions





Assembly Instructions

WII-0520 Hardware List M4 Allen Key Center Rail (3) Adjustable **4**) Bracket (2003) x 1 Bracket x 2 Foot **x 3** x 2 **(6)** Barrel Wood Screw Spring Wood Dowel (8) (M10 x 40mm) x 8 Nut x 21 (M4 x 32mm) x 12 Washer x 10 M6 x 15mm JCB M6 x 30mm JCB **10**) M6 JCN Nut (9) Flat Washer x 8 x 4 x 10 x 2 M6 x 60mm JCB 13) M6 x 35mm JCB 14 M6 x 40mm JCB 15 x 6 x 22 x 2 M6 x 90mm JCB M6 x 100mm JCB 16 17 x 16 4 Fix the Adjustable foot to the bottom of the Support Leg (L). Fit the Center Rail Bracket to the **Head / Footboard** Support (D). D 0 0 0 Q


> Short Tab of Metal Bracket (2)

Assembly Instructions






Assembly Instructions




Assembly Instructions

10 Fit the first 3 Slats and assemble the 14 Support Leg (L) to the Bed Slat (M). **Bolt & screw the Bed Slats (M)** 7 17 to the Side Rail (G) & Long Support (H). 14 M




11 Fit the other Slats out and assemble the Support Leg (L) to the Bed Slat (M). Bolt & screw the Bed Slats (M) to the Side Rail (G) & Long Support (H).




Assembly Instructions


NII-0520

Fit the other Slats out and assemble the Support Leg (L) to the Bed Slat (M).
Bolt & screw the Bed Slats (M) to the Side Rail (G) &



Bolt & screw the remaining Bed Slats (M) to the Side Rail (G).





Page 7 of 8

Assembly Instructions

WII-0520

Fit the Headboard Support Rails (B) to the Headboard Panel (A) & Side Rail (G).

