


Assembly Instructions

Caution: Please read this Assembly Instruction carefully before you proceed.








Please look under the Table Top for hardware packs.

Loveseat



CAUTION: This Loveseat is **NOT** a TOY.
Keep your child / children at bay during the assembly process.
Two adults may be needed to execute these actions.
Whenever lifting or moving the Loveseat and to prevent any damage to it.

Parts List


Label	Picture	Description	QTY
C		Backrest Panel	1
D		Right Leg Panel, pre-attached with Wooden Dowel	1
E		Left Leg Panel, pre-attached with Wooden Dowel	1
F		Front Apron Support Bar	1
G		Seat Panel	1
H		Seat Cushion	1
I		Backrest Cushion	2






Hardware

Label	Picture	Description	QTY
④		Bolt (M6x30mm)	3
⑤		Bolt (M6x35mm)	3
⑥		Bolt (M6x45mm)	5
⑦		Screws (M6x35mm)	7
⑧		Sleeve Nut (M6x15mm)	3
⑨		Allen Wrench	2

Assembly Preparation


Before Beginning Assembly:



-  Read instructions, cover to cover-
-  Have 2 adults on hand for assembly-
-  Do not assemble on flooring or carpet-
-  Assemble on a clean non-marring surface (packing foam)-
-  Save all packaging until finished-

Assembly Steps

Overview



Note : The Seat Panel (G) is not visible here as it is placed under the Seat Cushion (F).


This Loveseat has multiple parts and may require up to 30 minutes to assemble.
"To give you an overview of the Loveseat parts, the above picture is provided to help you put the various parts into perspective".
Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.

Step 2.




Place the **Backrest Panel (C)** upright as shown in the picture above onto a clean, soft surface to avoid any scratches or damage to the product.

With assistance from your adult partner(s), attach the **Right Leg Panel (D)** to the **Backrest Panel (A)**. Achieve this using **Bolts (5)** and the **Allen Wrench (9)** as shown in Figure 2.1.

Next, using 2 (two) **Allen Wrenches (9)**, turn in the **Bolts (4)**, and **Sleeve Nuts (8)** as shown in Figure 2.2.

Do not fully tighten the Bolts at this time.

Step 3




Place the Left Leg Panel (E) in an upright position, as shown in the picture above, onto a clean, soft surface to avoid any scratches or damage to the product.

With assistance from your adult partner(s), attach the **Left Leg Panel (E)** to the assembled parts in Step 2. Achieve this by using Bolts (5) and the **Allen Wrench (6)** as shown in Figure 3.1.

Using 2 (two) **Allen Wrenches (9)**, turn in the **Bolts (4)**, and **Sleeve Nuts (8)** as shown in Figure 3.2.

Do not fully tighten the Bolts at this time.


Step 4



With assistance from your adult partner(s), attach the **Front Apron Support Bar (F)** to the assembled frame in step 3. Achieve this by using **Bolts (6)** and the **Allen Wrench (9)** as shown above.

Do not fully tighten the Bolts at this time.


Step 5



With assistance from your adult partner(s), here in step 4, attach the **Seat Panel (G)** to the Seat Frame. Affix the **Screws (7)** using the **Allen Wrench (9)** as shown in the picture above.

Do not fully tighten the Screws at this time.

Step 6



Adjust Pre-installed Levellers
height for balance

Turn the **Loveseat** right side up.

Inspect the **Loveseat** and make sure all parts are adequately connected.

In a sequential manner, **tighten ALL Screws and Bolts at ALL joints.**

With assistance from your adult partner, adjust the **Levellers** to the desired height to avoid wobbles.


CAUTION : When tightening these screws and bolts, tighten sequentially.

DO NOT tighten any screw or bolt fully and then move towards the next one.

This could cause the frame to warp.

WARNING!! IF THE LOVESEAT IS NOT STABLE , IT COULD LEAD TO DAMAGE THE PRODUCT.

Step 7























Place the **Seat Cushion (H)** and the **Backrest Cushions (I)** onto the Loveseat.

Then affix the "**magic tape straps**" around the **Loveseat** as shown above

Your **Loveseat** is ready to be used.

This **Loveseat** can only be used on a flat, level surface.

Care & Maintenance

-   ● Do not put hot items directly on furniture surface
 -   ● Do not clean furniture with harsh cleansers or polish.
 -   ● To obtain the longest lifespan of your outdoor products, minimizing exposure to direct sunlight is recommended.
 -   ● Children should not climb or jump on the furniture.
 -   ● Do not write on furniture without a padded barrier to protect the surface.
 -   ● To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.
 -   ● Not for commercial use. For residential use only .
 -   ● Stains may be removed with mild soap solution and damp cloth.
 -   ● Keep away from sources of ignition.
-
-   ● Dust and pick-up spills using a clean, non-colored, lint-free cloth.