




INSTRUCTION MANUAL

STORAGE TOWER













BEFORE INSTALLATION

- Please list all parts as below first to check if any part is missing and make assembly easier.
- Do be careful that some parts are heavy and sharp.
- Please follow the assembly steps to install the product, if you find spare parts left, don't be worried, the left spare parts are prepared for bad ones if occurred.
- Once you hand tighten all of your bolts into place, we are going to use our wrench to fully tighten into place.
- Please do not exceed the bearing limitations of the product.
- Reconfirm that all bolts, screws, and knobs are secure every 90 days.
- Please retain these instructions for future reference.

TOOLS REQUIRED




PARTS




ASSEMBLY

PARTS REQUIRED


1



Ⓐ₁ 1PC




Ⓐ₂ 1PC



Ⓑ 1PC




Ⓒ 4PCS




Ⓓ 4PCS

2



Ⓔ 2PCS





Ⓕ 4PCS


ASSEMBLY

PARTS REQUIRED


3




Ⓒ 1PC



Ⓕ 4PCS





Ⓖ 2PCS



Ⓗ 5PCS


4



Ⓘ 6PCS



Ⓙ 6PCS




Ⓚ 12PCS




Ⓛ 6PCS

5



6



(M) 2PCS



(N) 2PCS