
ITEM NO.: 194S8367CH/TP#3

Assembly Instruction

ITEM NO: 194S8367CH/TP REVERSIBLE SECTIONAL


Thank you for your purchase of the Homelegance 8367 Reversible Sectional. Your new sectional can be assembled with either a left side facing chaise (configuration #1) or a right side facing chaise (configuration #2). See instructions below.

Configuration#1



see page 2~3 for assembly instruction

Configuration#2



see page 4~5 for assembly instruction

#194S8367CH/TP-3 LSF/RSF 3-SEATER, 1 PILLOW, REVERSIBLE

Configuration#1




COMPONENT LIST


NO.	DRAWING	QTY	DESCRIPTION
Α		1	BACK FRAME
В		1	SEAT FRAME
С		1	ARM FRAME
D		3	BACK CUSHION
Е		3	SEAT CUSHION
F		1	PILLOW
G	igorphi	4	LEG
Н	(a) (b) (b) (c) (c) (c) (c) (c) (c) (c) (c) (c) (c	2	BOLT
I		4	BOLT
J	Ö	6	LOCK WASHER
K	0	6	FLAT WASHER
L		1	ALLEN KEY

Please follow the drawings below to assemble the item.


Step 1




Step 2




Step 3




Step 4



Step 5




Step 6



#194S8367CH/TP-5 LSF/RSF CHAISE, 1 PILLOW, REVERSIBLE

Configuration#1





NO.	DRAWING	QTY	DESCRIPTION	
Α		1	BACK FRAME	
В		1	ARM FRAME	
С		1	SEAT FRAME	
D		1	LSF BACK CUSHION	
Е		1	RSF BACK CUSHION	
F		1	CORNER BACK CUSHION	
G		1	LARGE SEAT CUSHION	
Н		1	MIDDLE SEAT CUSHION	
I		1	CORNER SEAT CUSHION	
J		1	PILLOW	
K		4	LEG	
L	() ()	2	BOLT	
M	② ************************************	4	BOLT	
N	0	6	LOCK WASHER	
0	0	6	FLAT WASHER	
Р		1	ALLEN KEY	

Please follow the drawings below to assemble the item.

Step 1

C

C

M

OCCOOON

OCCOON

OCCOOON

OCCOON

OCCOOON

OCCOO

OCCOON

OCCOO

OCCO

OCCOO

OCCOO

OCCOO

OCCOO

OCCOO


OCCOO


OCCOO


OCCOO

OCCOO

Step 4










194S8367CH/TP-3 LSF/RSF 3-SEATER, 1 PILLOW, REVERSIBLE


Configuration#2





COMPONENT LIST


NO.	DRAWING	QTY	DESCRIPTION
Α		1	BACK FRAME
В		1	SEAT FRAME
С		1	ARM FRAME
D		3	BACK CUSHION
Е		3	SEAT CUSHION
F		1	PILLOW
G	\Diamond	4	LEG
Н	(i) (i) (ii) (ii) (ii) (ii) (ii) (ii) (2	BOLT
I		4	BOLT
J	٥	6	LOCK WASHER
K	0	6	FLAT WASHER
L		1	ALLEN KEY


Please follow the drawings below to assemble the item.















194S8367CH/TP-5 LSF/RSF CHAISE, 1 PILLOW, REVERSIBLE

Configuration#2







NO.	DRAWING	QTY	DESCRIPTION	
Α		1	BACK FRAME	
В		1	ARM FRAME	
С		1	SEAT FRAME	
D		1	LSF BACK CUSHION	
Е		1	RSF BACK CUSHION	
F		1	CORNER BACK CUSHION	
G		1	LARGE SEAT CUSHION	
Н		1	MIDDLE SEAT CUSHION	
I		1	CORNER SEAT CUSHION	
J		1	PILLOW	
K		4	LEG	
L	(<u>)</u>	2	BOLT	
M	2-3 ₁₆ " —	4	BOLT	
N	0	6	LOCK WASHER	
0	0	6	FLAT WASHER	
Р		1	ALLEN KEY	

Please follow the drawings below to assemble the item.


Step 1




Step 4




Step 2




Step 5



Step 3



Step 6



CARE INSTRUCTION FOR 100% POLYESTER FURNITURE:

In order to maintain the original appearance of your 100% polyester furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage 100% polyester. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use window treatments to block the sun's rays.
- Wipe with a soft brush to remove dust.
- Wipe 100% polyester with professional cleanser.



For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.

Assembly Instruction

ITEM NO: 194S8367CH/TP-4

OTTOMAN

NOTE: Do not use power tools for assembly. Power tools increase the risk of over tightening which lead to splitting or cracking the wood.


COMPONENT LIST

NO.	DRAWING	QTY	DESCRIPTION
Α		1	OTTOMAN
В		4	LEG


Please follow the drawings below to assemble the item.

Legs are stored in the box and put in the bottom of ottoman. Please take out for assembly.


Step 1



Step 2



Completed.



CARE INSTRUCTION FOR 100% POLYESTER FURNITURE:

In order to maintain the original appearance of your 100% polyester furniture, please follow below care procedures:

- Avoid exposing furniture directly to sunlight or heating and air conditioning outlets. Sunlight and / or exposure to heating and air conditioning outlets will fade/damage 100% polyester. Do not place your upholstered furniture too close to windows, radiators, or vents, and be sure to use window treatments to block the sun's rays.
- Wipe with a soft brush to remove dust.
- **●** Wipe 100% polyester with professional cleanser.
- For items use on wooden floor, hard surfaces or carpets, it is recommended to Install protective pads under all legs and supports to avoid/prevent from damages/scratches and discoloration.