
Assembly Instructions

Caution: You must read this before you proceed

Please look underneath the Seat Panel for Hardware Packs

BARSTOOL



CAUTION: This Barstool is NOT a TOY.

Keep your child / children at bay during the assembly process.


For turning the Barstool and to prevent damage to the Barstool, 2 people may be needed to execute this action.

Parts List				
Label	Picture	Description	QTY	
Α		Back Panel	1	
В		Seat Panel	1	
С		Right Leg Panel	1	
D		Left Leg Panel	1	
E		Support Bar	2	

<u>Hardware</u>				
Label	Picture	Description	QTY	
1		Bolt (M6x50mm)	5	
2		Bolt (M6x45mm)	7	
3		Screw (M6x60mm)	7	
4		Washer (M6/18x2mm)	11	
(5)		Allen Wrench(M4)	2	

Assembly Preparation

Before Beginning Assembly:





Read instructions, cover to cover-



Have 2 adults on hand for assembly-




• Do not assemble on flooring or carpet-




Assemble on a clean non-marring surface (packing foam)-




Save all packaging until finished-



This Barstool has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Barstool, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.






Position the Seat Panel(B) to the Back Panel(A) as shown in the above picture.

Attach the Seat Panel(B) to the Back Panel(A) using the Bolts(\bigcirc), Washers(\bigcirc) with the Allen Wrench(\bigcirc).


Do not fully tighten the Bolts.



With assistance from your adult partner, position the assembled part in Step 2 to the Right Leg Panel(C) as shown in the above picture.

Then, attach the Seat Panel(B) to the Right Leg Panel(C) using the Bolts(2), Washers(4) with the Allen Wrench(5).


Do not fully tighten the Bolts.



With assistance from your adult partner, turn the assembled part in Step 3 into the opposite side.

Position the Support Bar(E) to the Right Leg Panel(C) as shown in the above picture. Then, secure the Support Bars (E) to the Right Leg Panel(C) using the Screws(3) with the Allen Wrench(5).


Do not fully tighten the Screws.




With assistance from your adult partner, position the assembled part in Step 4 to the Left Leg Panel(D) as shown in the above picture.

Secure the Seat Panel(B) to the Left Leg Panel(D) using the Bolts(2), Washers(4) with the Allen Wrench(5).


Do not fully tighten the Bolts.



With assistance from your adult partner, turn the Barstool into the opposite side as shown in the above picture. Secure the Left Leg Panel(D) to the Support Bars(E) using the Screws(3) with the Allen Wrench(5).



With assistance from your adult partner, turn the Barstool right side up. Secure the Leg Panels(C, D) to Back Panel (A) using the Screws(\mathfrak{F}) with the Allen Wrench(\mathfrak{F}).



Inspect it and make sure all parts are adequately connected.

Carefully sit onto the Barstool. This pressure will help align all parts at all joints.

Then get off the Barstool and proceed to tighten the Bolts and Screws in a sequential manner.

When tightening the Bolts and Screws tighten sequentially.

DO NOT tighten any Bolt or Screw fully and then move on towards the next one.

If there are any wobbles after tightening, loosen the Bolts and Screws and execute this same process.

Adjust the Levelers until the Barstool is level with the ground.

To adjust the Levelers, get assistance from an adult partner to lift/lean and hold the Barstool while you are working.

Your Barstool is ready for use.

This Barstool can only be used on a flat, level surface.

Care & Maintenance



Do not put hot items directly on furniture surface



Do not clean furniture with harsh cleansers or polish.



To obtain the longest lifespan of your outdoor prodcts, minimizing exposure to direct sunlight is recommended.



Children should not climb or jump on the furniture.



Do not write on furniture without a padded barrier to protect the surface.



To obtain the longest lifespan of your outdoor products, avoid extended and lengthy exposure to rain, snow, and direct sunshine. Whenever possible cover the product and /or place under patio or awnings.



Not for commercial use. For residential use only.



Stains may be removed with mild soap solution and damp cloth.



Keep away from sources of ignition.



Dust and pick-up spills using a clean, non-colored, lint-free cloth.