


Assembly Instructions





Caution: •You must read this before you proceed.

•Set often ship in multiple boxes and may arrive a day or two apart.








Dining Chair



Parts List


| Label | Picture | Description | QTY |
|-------|---|--------------|-----|
| A |  | Back Rest | 1 |
| B |  | Cushion Seat | 1 |
| C |  | Seat Frame | 1 |
| D |  | Front Leg | 2 |

Hardware

| Label | Picture | Description | QTY |
|-------|---|---------------------|-----|
| ① |  | Allen Wrench | 1 |
| ② |  | Bolt (M6 x 35mm) | 3 |
| ③ |  | Bolt (M6 x 60mm) | 5 |
| ④ |  | Bolt (M6 x 70mm) | 5 |
| ⑤ |  | Spring Washer (M6) | 11 |
| ⑥ |  | Washer (M6) | 11 |
| ⑦ |  | Screw (M4 x 25mm) | 7 |

Assembly Preparation

Before
Beginning
Assembly
:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-


Assembly Steps

Overview




This Chair has multiple parts and may require up to 30 minutes to assemble. To give you an overview of the Chair parts, the above picture is to help you put the various parts into perspective. Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Step 1



Unpack and place all parts on a clean, non-marring surface.


Step 2



2.1: Place the Back Rest (A) as shown above. Attach Seat Frame (C) to Back Rest (A) using Bolt (②) , Spring Washer (⑤) and Washer (⑥) with Allen Wrench (①).


2.2: Then fix the Seat Frame (C) and Back Rest (A) with Bolt (④) , Spring Washer (⑤) and Washer(⑥) using Allen Wrench (①).
Do not fully tighten the Bolts.

Step 3




Attach Front Leg (D) to Seat Frame (C) using Bolt (③), Spring Washer (⑤) and Washer (⑥) with Allen Wrench (①).
Do not fully tighten the Bolts.

Step 4



Then, turn the Dining Chair upside down and fix the Cushion Seat (B) using Screw (⑦) with Screwdriver (Not Provided).
Tighten the Screws fully.

Step 5



Turn the Dining Chair right side up.
Place the Dining Chair on a **LEVEL SURFACE**.
Inspect it and make sure all parts are adequately connected.
Gently and gracefully, sit into to the Dining Chair.
This would help to align all the parts at all the joint areas.

Then get off the Dining Chair, and in a sequential manner, proceed to tighten all Bolts.

CAUTION 1: When tightening the Bolts, tighten sequentially.
DO NOT tighten any bolt fully and then towards the next one.
This would cause the frame to warp.

If there is still wobbles, loosen the bolts and execute this same process.

WARNING!! IF DINING CHAIR IS NOT STABLE , IT COULD LEAD TO DAMAGING THE PRODUCT.

Ensure all bolts are fully locked into position.

The Dining Chair is ready to be used.

Caution 2: This Dining Chair can only be used on a flat, level surface.

Care & Maintenance



- Furniture may scratch floors. We recommend using furniture pads to protect your floors.



- Do not put hot items directly on furniture surface.



- Do not clean furniture with harsh cleansers or polish.



- Do not place furniture under direct sunlight.



- Do not place furniture near heating or cooling vents.



- Do not write on furniture without a padded barrier to protect the surface.



- Do not place furniture outside . For indoor use only.



- Not for commercial use. For residential use only.



- Stains may be removed with mild soap solution and damp cloth.



- Children should not climb or jump on the furniture.



- Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Questions & Answers about Proposition 65

- What is Proposition 65?

Proposition 65 requires businesses to provide warnings to Californians about significant exposures to chemicals that cause cancer, birth defects or other reproductive harm. These chemicals can be in the products that Californians purchase, in their homes or workplaces, or that are released into the environment. By requiring that this information be provided, Proposition 65 enables Californians to make informed decisions about their exposures to these chemicals.

Proposition 65 also prohibits California businesses from knowingly discharging significant amounts of listed chemicals into sources of drinking water.

Proposition 65 requires California to publish a list of chemicals known to cause cancer, birth defects or other reproductive harm. This list, which must be updated at least once a year, has grown to include approximately 900 chemicals since it was first published in 1987.

- What types of chemicals are on the Proposition 65 list?

The list contains a wide range of naturally occurring and synthetic chemicals that include additives or ingredients in pesticides, common household products, food, drugs, dyes, or solvents. Listed chemicals may also be used in manufacturing and construction, or they may be byproducts of chemical processes, such as motor vehicle exhaust.

- What does a warning mean?

If a warning is placed on a product label or posted or distributed at a workplace, a business, or in rental housing, the business issuing the warning is aware or believes that it is exposing individuals to one or more listed chemicals.

By law, a warning must be given for listed chemicals unless the exposure is low enough to pose no significant risk of cancer or is significantly below levels observed to cause birth defects or other reproductive harm.

- Where can I get more information on Proposition 65?

If you have specific questions on the administration or implementation of Proposition 65, you can contact OEHHA's Proposition 65 program at P65.Questions@oehha.ca.gov, or by phone at (916) 445-6900.