

Your furniture purchase is an investment. Here are a few tips to maximize the lifetime of your furniture with a minimum amount of effort. Properly caring for your furniture can help ensure that it looks great year after year.

Wood Furniture Maintenance:

- Always dust, wipe, and clean *with* the grain of the wood.
- Dust with a soft cloth. Dust will scratch the furniture surface if not removed properly.
- Use the same type of polish consistently as interchanging oil-based and wax-based polishes will cause a build-up and result in a foggy or cloudy appearance.
- If a polished surface becomes foggy, rub it with a cloth dipped in a solution of one tablespoon vinegar to one quart of water. Rub softly with the grain until the surface is completely dry.
- Soap and water are not advisable for wood surfaces. Water can penetrate the finish and raise the grain on wood, causing damage.
- Remember to change dusting cloths frequently as dirty cloths may scratch your furniture's surface.

The Enemies of Wood:

- Moisture is wood's worst enemy. Liquid spills should be gently wiped up immediately. Coasters should be used under all beverages.
- Do not allow rubber or vinyl materials to lie on the furniture. Chemicals in rubber may leave a stain. Put a strip of felt or leather under accessories that have rubber or vinyl.
- Heat creates a chemical change in the furniture's finish, which results in a white spot. Use protective pads under hot dishes, appliances, etc.
- Sunlight's ultraviolet rays can damage the finish of furniture. Do not place furniture directly against a heater or radiator and do not place in the path of hot streams of air from central heating. This will cause extreme localized drying of the wood.

High Gloss Resin Table Maintenance:

- Resin tabletops have approximately 1/8" of a resin coat on the top face of the table, which will resist ice, water, wine, liquor, food, cleaning fluids, and warm or hot liquids; however, cups, glasses, etc. containing hot liquids should not be left on the table without a coaster for protection.
- Resin tabletops will scratch just the same as any other glossy surface and basic precautions should be taken.
- For lasting shine, the resin table should be waxed with a car wax that does not contain silicon. Maintaining this wax build-up will result in a high gloss shine.
- When wiping down the table, a soft, clean rag should be used. Do not use a heavy paper.

Granite Top Maintenance:

The surface of the granite on your table has been polished or sealed to create a generally non-porous surface. The stone has many natural characteristics including: veining, hairline cracks, and color variations - which make up the stone's beauty.

To maintain the beauty of your granite:

- Protect surfaces from scratching, staining and etching by:
 - * Keeping them free of debris or sharp objects
 - * Wiping up spills immediately
 - * Avoiding contact with chemicals (particularly acid-based materials)
- Clean with pH neutral products or those especially formulated for use on stone.
- It is not recommended to use a water-based solvent for dark granite as it will remove the polish from the surface. absorbed into the stone.
- After a period of use, apply a penetrating sealer to prevent contaminants from being
- Remove stains with special absorbent poultices formulated for use on stone.
- Renew the surface on polished granite (granite with a high gloss surface) by buffing with special stone polish, powder or cream.
 - Do not use granite polish on granite with a matte finish, which has been honed rather than polished. (Penetrating sealer may be used on both polished and honed granite.)

Marble Top Maintenance:

Marble may be stone, but it is porous stone and can stain easily. Treating marble surfaces the same as wood surfaces is a great rule of thumb.

- It is recommended to seal the tops on a regular basis (every 6 to 12 months). A good quality stone sealer can be purchased from any tiles/stone store or any homeware store and should be applied according to the manufacturer's recommendation.
- When sealed properly, marble tops can be used indoors and outdoors and can withstand any weather conditions except internal freezing. Snow or freezing rain will penetrate the table and cause cracks.

Caring for the Fabric on Upholstered Furniture:

- Frequent vacuuming of the entire upholstered area will prevent dust from settling into the fibers.
- Professional cleaning is always recommended for all upholstered pieces.
- Always pre-test a small area of fabric in an inconspicuous area when cleaning before proceeding.
- Do not use cleaning products containing brightening agents.

VERY IMPORTANT!!

NEVER
USE GLASS CLEANERS
ON FINISHED SURFACES.
AMMONIA WILL
CHEMICALLY ATTACK
THE FINISH.

DO NOT
WRITE
DIRECTLY
ON
SURFACE



**PREVENT
MARKING**

DO NOT
PLACE
DIRECTLY
IN
SUNLIGHT



**PREVENT
FADING**

DO NOT
USE
PLACEMATS
WITH
RUBBER
BASES



**PREVENT
DISCOLORING**

NEVER
ALLOW LIQUIDS OF ANY
KIND TO LINGER ON
SURFACES. ABSORPTION
CAUSES THE WOOD TO
WARP AND THE FINISH
TO DE-LAMINATE.

DO NOT USE
COMMERCIAL
POLISHES
AND WAXES



**PREVENT
YELLOWING**

DO NOT
PLACE HOT
POTS, ETC.
ON
SURFACE



**PREVENT
DAMAGE TO
FINISH!**


REGULATE
THE
HUMIDITY
CONDITIONS
AT YOUR
HOME



**PREVENT
SPLITTING**

ASSEMBLY INSTRUCTIONS


DO NOT FULLY TIGHTEN ALL BOLT AND SCREWS UNTIL THE ENTIRE UNIT IS COMPLETELY ASSEMBLED



Step 1: Place Bench Top (A) on a piece of cloth or carpet to prevent from scratching.

Attach LSF Front/ RSF Back Leg (B) and RSF Front/ LSF Back Leg (C) to Bench Top (A) by using Flat Washer (3), Lock Washer (2), Allen Bolt (1) and Allen Key (6). Do not fully tighten.

Attach Side/ Front Stretcher (D/F) to the middle of four Legs and inserting Long Screw (4). Attach the Center Stretcher (E) to the middle of two Front Stretcher (F) by inserting Short Screw (5), as the picture shown. Secure all screws with Phillips -head screw drivers (not provided).









Step 2: Turn the Bench to upright position and place it on flat surface and adjust legs so the Bench is level and does not wobble.







Tighten all Bolts and Screws with Allen Key (6) provided and Phillips-head screw drivers (not provided). Assembly product is completed.

PARTS LIST


P. 3/4

| (A) BENCH TOP 1 PC | (B) LSF FRONT/ RSF BACK LEG 2 PCS | (C) RSF FRONT/ LSF BACK LEG 2 PCS |
|---|---|--|
|  |  <p>Sticker stick on the part (L)</p> |  <p>Sticker stick on the part (R)</p> |
| (D) SIDE STRETCHER 2 PCS | (E) CENTER STRETCHER 1 PC | (F) FRONT STRETCHER 2 PCS |
|  |  |  |

HARDWARE LIST

| NO. | DESCRIPTION | | DIMENSION | QTY' |
|-----|-------------|---|-----------------|-------|
| 1 | Allen Bolt |  | Ø 1/4" x 60 mm | 8 pcs |
| 2 | Lock Washer |  | Ø 5/16" x 13 mm | 8 pcs |
| 3 | Flat Washer |  | Ø 5/16" x 19 mm | 8 pcs |
| 4 | Long Screw |  | Ø 4 x 50 mm | 8 pcs |
| 5 | Short Screw |  | Ø 4 x 40 mm | 2 pcs |
| 6 | Allen key |  | 4 mm | 1 pc |

PARTS **COMPLETE HARDWARE**



Fabric Content: 100% POLYESTE

This fabric is not machine washable.

Allow +/-3% residual shrinkage.

Do not use cleaning products containing brightening agents.

PRODUCT DETAILS

SEAT BOX

LEG

STRETCHER

PRODUCT SIZE

CARTON SIZE

NET WEIGHT

GROSS WEIGHT

CU.FT.

ACACIA WOOD + RUBBER WOOD

ACACIA WOOD

RUBBER WOOD

54" X 18.5" X 25.75" H

56.3"x 20.08" x6.49" H

37.4 LBS

41.8 LBS

4.25'

MADE IN VIETNAM