# Thank You For Shopping With COZAYH HOME

We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.

Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: Support@cozayh.com

Website: www.cozayhhome.com




### **Assembly Instructions**

Laying out and identifying all the parts on the instruction may help smooth out the assembly. Using WRONG screws will irreversibly damage the table top!


ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY
Α		Table top	1	Ε		Ball foot	4		0	Washer	7
В		Child leg	3	F	7	Leveling foot	4	J		Allen wrench	1
С		Parent leg	1	G		Screw (6x20mm)	4	K		Dust cap	4
D		Lower shelf	1	Н		Screw (6x30mm)	3	NOTE: Using WRONG screws will irreversibly damage the table top!			

#### STEP ONE




Use the SHORTER screws G to attach the child legs B and parent leg C to the table top A. Do NOT fully tighten the screws till you put on the lower shelf.

#### **STEP TWO**



Use the LONGER screws H to attach the child legs B to parent leg C. Place the lower shelf and attach the ball feet E to the legs.

#### STEP THREE



Attach the leveling feet F. Insert the dust cap K to the assembly holes on the legs.

## A

#### **WARNING**

- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 25 Lbs. Do NOT overload.



COZAYH HOME