



# LIBERTY FURNITURE

## ASSEMBLY INSTRUCTION

ITEM# : 2094-AC3002

DESCRIPTION: ACCENT CHAIR

**Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.**



### PART LIST

NO.	DRAWING	DESCRIPTION	Q'TY
1		Chair back Assembly	1
2		Chair seat	1
3		Leg Assembly	2

### HARDWARE LIST

NO.	DRAWING	DESCRIPTION	Q'TY
A		Bolt Ø5/16"-18*65mm(L)	07
B		Flat Washer Ø5/16"* 25mm	07
C		Spring Washer * 15mm	07
D		Allen Key 6mm	01

### STEP 1

