



**3910 / 3950 - 280 DRESSER**

**Assembly Instruction**






<b>A. Components :</b>	<b>Qty</b>
1. Bun Feet :	4 Pcs
2. Center Leg :	1 Pc


**STEP - 1**



3910 / 3950 - 280 DRESSER

Assembly Instruction

A. Components :	Qty				B. Hardware :	Qty
1. Dresser	1x				a. Screw ø8 x 2"	1 x
					b. Screw ø8 x 5/8"	1 x
					c. Restrain Strap	1 x
					d. Metal Tabs	2 x
					e. Plastic Wall Anchor	1 x



**⚠ WARNING**

Serious or fatal crushing injuries can occur from furniture tipover. To help prevent tip-over :

- Install tipover restraint provided.
- Place heaviest items in the lowest drawers.
- Unless specifically designed to accommodate, do not set Tv's or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time.
- (OR)
- Do not defeat or remove the drawer interlock system.

**Use of tip over restraints may only reduce, but not eliminate the risk of tip-over.**  
*This is a permanent label. Do not attempt to remove.*