

Thank You For Shopping With COZAYH HOME

We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.

Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: Support@cozayh.com



Website: www.cozayhhome.com

SKU: X03020




Assembly Instructions

Laying out and identifying all the parts on the instruction may help smooth out the assembly.


ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY
A		Cabinet body	1	C		Wood leg	2
B		Bolt&washer (8x45mm)	4	D		Allen key	1

STEP 1




Flip the cabinet body upside down.

STEP 2



Attach the wood legs to cabinet body.

STEP 3



Finish product.



WARNING

- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard – Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 50 Lbs. Do NOT overload.



COZAYH HOME