












Thank You For Shopping With COZAYH HOME

We value your feedback and want to hear from you. To let us know how we can improve your shopping experience, or to ask a specific question about your order, please find our contact information below.

Customer Service Line: 1.312.600.5553 (M-F 9am-5pm Central Time)

Customer Service Email: Support@cozayh.com

Website: www.cozayhhome.com

SKU: BY-TB005		Assembly Instructions					
		Laying out and identifying all the parts on the instruction may help smooth out the assembly.					
ITEM	PART	DESC.	QTY	ITEM	PART	DESC.	QTY
A		Table top	1	D		Bolts (6×35mm)	4
B		Wooden leg	1	E		Allen wrench	1
C		Wooden leg	1	F		Flat washers	4
STEP 1 		STEP 2 		STEP 3 		STEP 4 	
Turn table top upside down on clean and soft surface.		Attach wooden leg "B" to the bottom of the table top by bolts and flat washers as shown above.		Attach wooden leg "C" to bottom of table top by bolts and flat washers.		Turn the table upright. Please make sure all the bolts are fully tightened before using this table.	



WARNING

- Do not dispose of any packaging or contents of the shipping carton until assembly is completed to avoid accidentally discarding small parts or hardware.
- Choking Hazard – Adult assembly required. It may contain small parts and sharp points.
- Do NOT use power tools.
- This product can hold a maximum load of 25 Lbs. Do NOT overload.



COZAYH HOME