CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.



NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Weight Capacity: 600 Ibs

Warning: Do not stand on chair

Warning: Do not over torque bolts / screws








Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
Α	Leg Frame		4X
В	Back frame		1X
С	Side frame		1X
D	Seat Frame		1X
Е	Cushion Seat		1X
F	Cushion Back		2X
F1	Cushion Side	J	1X
G	Pillow		1X
Н	Bolt	M8x65	12X
1	Bolt	(M8X35)	8X
K	Inset Nut	(M8X15)	8X
L	Washer	M8.5/20X15	12X
М	Allen key	LG4	2X

Model# PAT7054A

Product Dimensions:29.13" W x 54.72" D x 27.16" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key



Step 1
Attach leg frame (A) to Frame seat (D) ,use Bolt (H) and Washer (I),tighten with allen key (M).

Step 2
Tighten Bolt (I) and Insert nut (K) with allen key (M) to attach seat frame (D) and back frame (B), side frame (C).


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

3



4



Step 3
Attach cushion seat and cushion back, Side cushion.

Step 4 Complete