


Assembly Instructions


SKU:KHD-MX-NS19-RBN
Lot NO.:MX-NO.1


Before You Start

⚠ Most of the board parts are Labeled. Have a check to make sure all parts are included.

⚠ Keep the handtools close at hand. Do not use power tools to assemble your furniture as they may scratch or damage the parts.









Return Policy


VECELO believes you will absolutely love your new item. But if for some reason you want to return it, please contact us directly before you decide to return your product. Our customer service organization can answer most concerns and assist you with any questions you may have about your new item. Please email us first at: support@vecelo.com.

The item must be returned within 30 days or delivery for a full refund. The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories. Trouble shooting:





We control manufacturing and distribution ourselves to ensure the quality.



Care and Maintenance

- It is best to keep your furniture in a climate-controlled environment.
- Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood.
- It is advised to keep furniture away from direct sunlight as sun may damage the proper care and cleaning at home will extend the life of your purchase.
- Following these important and helpful tips will enhance your furniture as it ages.