

ASSEMBLY INSTRUCTION






ITEM NO.: 193D1133-24S/29S










Swivel Pub Stool

IMPORTANT NOTE :

- To prevent scratch, place all wooden parts on a clean and smooth surface such as carpet.
- Keep all hardware parts out of reach of children
- Follow assembly instruction step by step




PARTS LIST	
(A) 	(C)  Footrest -1 Pc
(B) 	(D)  Apron with swivel plate -1 Pc
(E) 	Chair Leg ----4 Pcs


HARDWARE LIST		
No	Description	QTY
1	JCBC Screw M6 x 25mm 	4 Pcs
2	JCBC Screw M6 x 40mm 	12 Pcs
3	JCBC Screw M6 x 45mm 	6 Pcs
4	Spring Washer M6 x 13mm 	18 Pcs
5	Flat Washer M6 x 13mm 	12 Pcs
6	Flat Washer 6.5 x 16.5mm 	6 Pcs
7	Flat Washer 1/4" x 19mm 	4 Pcs
8	Wood Dowel M10 x 35mm 	4 Pcs
9	Allen Key M4 (Long) 	1 Pc

NOTE : Do not tighten all screws until the stool is fully set-up.


STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

