

CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening




Model# DSK2209

Product Dimensions: 43.3"W×21.7"D×29.5"H

Part List and Hardware List



HW1x1 	HW2x8 	HW3x6 6x95mm	HW4x2 6x45mm	HW5x2 6x20mm	HW6x4 6x12mm	HW7x12
HW8x2 	HW9x2 	HW10x6 4x35mm	HW11x6 	HW12x6 	HW13x10 4x25mm	HW14x4 5x50mm




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 60 minutes.


1




2




3




4




5




6




7




8




9




10




11



12



13



14

