#### **CARE AND MAINTENANCE**

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

### NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening

## Part List and Hardware List

Ax1	Bx2	Cx1	Dx1	Ex1
		• •		
Fx1	Gx1	Hx1	lx1	Jx1
Kx1	Lx1	Mx2	Nx2	Ox2
HW1x1	HW2x8	HW3x16	HW4x16	HW5x11
67		<b>■</b> □=\{\}	<b>®</b>	3.5x14mm
HW6x2	HW7x1	HW8x4	HW9x12	HW10x16
4x12mm		4x35mm	6x10mm	6x16mm
HW11x1				



#### Model# FOX2207A

Product Dimensions: 43.3"W×19.7"D×29.5"H



# **PREPARATION**

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.

If any part is missing or damaged, do not attempt to assemble the product. Estimated Assembly Time: 60 minutes.











