

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.








Remove wooden furniture from standing water. Dust regularly with small brush or vacuum









Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Frame back		1X
B	Frame Seat		1X
C	Frame Leg 1		1X
D	Frame Leg 2		1X
E	Side Rail		2X
F	legconnection		1X
G	Cushion seat		1X

PIECE	DESCRIPTION	PICTURE	QUANTITY
I	Bolt	 M8x85	4X
K	Bolt	 M8x60	4X
L	Bolt	 M8x40	2X
M	Bolt	 M6x50	2X
N	Washer	 M8.5/20X20	10X
O	Screws	 M4x45	6X
P	Allen key	 LG4	1X
Q	Screw Driver	 Not Provied	1X

 **SAFAVIEH**
O U T D O O R

Weight Capacity : 600 Ibs


Warning : Do not stand on chair

Warning : Do not over torque bolts / screws



Model# CPT1020

Product Dimensions: 25" W x 25" D x 40.06" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1



2



Step 1

Attach leg frame (A) to Frame Table (B) ,use Bolt (I) and Washer (N), tighten with allen key (P).

Step 2

Use .Bolt (L) and Wassher (N), tighten with allen key (P).


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

3




Step 3

Attach leg (D) to Frame Seat (B) ,use Bolt (K) and Washer (N), tighten with allen key (P).

Then, place (E) into the housing of the Hind leg of the Chair Back(A) and Front Leg (D)

Attach Front Leg (D) and Chair back (A) use Bolt(M) tighten with allen key (P)

4



Step 4 Attach leg (C) to Frame Seat (B) ,use Bolt (K) and Washer (N), tighten with allen key (P).

Then, place Side Rail (E) into the housing of the Hind leg of the Chair Back(A) and Front Leg (C)

Allach leg connection (F) into the housing of the Front legs(C),(D)

Attach Front Leg (C) and Chair back (A) use Bolt(M) tighten with allen key (P)


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key


5



Step 5

Secure the Leg Connection(F) to Front Legs (C),(D) and Side Rail (E) to Chair Back(A) and Front Leg (C) by using Screw(O) and Screwdriver(Q).

6



Step 6

Attach cushion in chair and Complete.