



# INSTRUCTION MANUAL

Fujimori Cabinet  
IF-496






Estimated Time for Assembly

**60 min**






Weight Limitation (Evenly)

**260 lb** overall



Tools Needed(Not included)







## Warning

Serious or fatal crushing injuries may occur if the furniture tip-over. Furniture must permanently fixed to the wall with included anti-tipping device to prevent the furniture from tipping over.

Different wall materials requires different types of fixing device, Use suitable fixing device to secure the stability and load bearing capacity of the furniture. If you are uncertain about which type of fixing device to use, please contact your local hardware store.













Assemble the furniture on empty carton, carpet, or rug to prevent scratches or damage.













This furniture requires 2 people to assemble.

Make sure no parts are missing or damaged before assembly.


# PART LIST

<b>A</b>	<b>B</b>	<b>C</b>	<b>D</b>	<b>E</b>
				
Top Panel 1 PC	Bottom Panel 1 PC	Left Panel 1 PC	Right Panel 1 PC	Left Door Frame 1 PC
<b>F</b>	<b>G</b>	<b>H</b>	<b>I</b>	<b>J</b>
				
Right Door Frame 1 PC	Back Bar 1 PC	Back Panel 2 PCS	Shelf Panel 1 PC	Legs 4 PCS

# HARDWARE LIST


<b>#1</b>	<b>#2</b>	<b>#3</b>	<b>#4</b>	<b>#5</b>
				
Ø8*30mm Wood Dowel 8 PCS+1	Ø1/4*38mm Bolt 4PCS	Door Magnet 2 PCS	12mm*Ø3**D6mm Screw 4PCS+1	Ø 3*18mm Screw 18 PCS+2
<b>#6</b>	<b>#7</b>	<b>#8</b>	<b>#9</b>	<b>#10</b>
				
Shelf Holder 4PCS	Ø 4.5*19mm Round Head Bolt 2 PCS	Handle 2 PCS	Allen Wrench 1 PC	Safety Strap Kit 1 SET

Please do not use tools to assemble this unit unless specifically indicated.




Reference the images above any time the instructions state "lock the hardware."  
Note:Be sure to check all hardware is locked when completed.

Step 1.




Attach door magnet(3) to top panel (A) and bottom panel(B) using screw(4).  
Insert wood dowel(1) to left panel(C) and right panel(D) and bolt(2) to bottom panel(B).  
and then lock with the allen key (9).

Step 2.




Fix four legs(J) as is shown in the figure.

Step 3.




Buckle the back bar (G) into the bottom panel(B) as is shown in the figure.


Step 4.




Slide back Panel(H)into grooves as per diagram.

Step 5




#1  X4



Insert wood dowel(1)to left panel(C) and right panel(D).


## Step 6.



#5  X 18

Lock the screw (5) into the component (A.B.C.D.G).


## Step 7.



Slide door frames (E.F) as shown above, and align holes reserved in both top and bottom panel.(When holes are aligned, you usually can hear a slight clicking sound as they lock into place.)










## Step 8.




Insert the shelf holder(6)into the left panel(C)and right panel(D)horizontally.  
And place the shelf panel (I) in parallel.This is shown in the figure above.  
The handle(8) is fixed on the left door frame(E) and right door frame(F)  
and is locked with round head bolt(7).

## Step 9.



#10	A	B	C	D	E
			 D8*3/4"	 D8*1- 1/2"	
Safety strap kit 1SET	Wall Anchor 1pc	Washer 2pcs	Short Screw 1pc	Long Screw 1pc	Safety Wall Strap 1pc



Drill 1 hole on the wall.  
 Insert wall anchor(A)into the wall.  
 Using screwdriver to secure safety wall strap(E) to cabinet with short screw(C).  
 The short screw(C) through washer(B)and safety wall strap(E) to cabinet.  
 Secure cabinet to wall with long screw(D) through washer(B)and safety wall strap(E)to wall anchor(A) by using screwdriver.

**FINISH!**

# USE & CARE INSTRUCTIONS

## KEEPING YOUR FURNITURE BEAUTIFUL

Quality furniture is a significant investment expected to last for years on end. To maintain its beauty & help it last, furniture needs the right care, as no finish is totally indestructible. However, with regular care, the finish will last much longer, providing years of enjoyment to you.

## TIPS TO PROTECT & CARE FOR YOUR FURNITURE

1. Avoid placing your furniture in direct sunlight, as sunlight causes fading.
2. Avoid extreme changes in temperature by arranging furniture away from radiators, heat & air vents & air conditioning units.
3. Avoid placing plastic or rubber materials (lamp bases, notebooks, placemats, etc.) on your furniture, as certain plastics contain ingredients that may damage the finish.
4. Periodically rotate accessories on furniture, do not sit in the same place all the time.
5. Use pads, cloth or felt to protect the furniture surface from plastic, rubber, hot dishes beverages, bookends, flowerpots & vases.
6. Clean up spills immediately, using a blotting rather than wiping action, as water left over a long time will cause white spots in the finish. Alcohol, perfume, after-shave & medications can cause severe finish damage.
7. Use a protective pad when writing on the furniture surface.
8. Lift & place objects rather than dragging them across the furniture surface.
9. Avoid placing furniture directly under windows.
10. Use cutting boards and trivets for food preparation in order to avoid damaging the top of the furniture

## WOOD FURNITURE CARE

We recommend dusting frequently with a clean, soft, dry, lint-free cloth. Wipe spills immediately with a clean cloth. Clean the surface by rubbing follow the direction of the grain and wipe dry. We recommend polishing your furniture approximately every six months. We do not recommend use aerosol-powered cleaners, polishes that contain silicone, waxes, abrasives, or oil based.

## LEATHER FURNITURE CARE

To prevent cracks and surface damage we recommend keeping away from high humidity and low temperature rooms. Do not place close to fire, stoves or heaters. Wipe spills immediately with clean non-abrasive cloth or sponge. For spots or stains, clean with mild detergent and warm water. Wring out excess water make cloth is damp before use. Rinse cloth in clear water and wring out, then wipe again to remove detergent residue. To prevent damage use a dry cloth to wipe excess moisture. Also, do not use chemical cleaners that contain bleach.

## GRANITE CARE

Our granite is sealed. We recommend cleaning spills promptly. For daily cleaning, use warm water and a soft clean cloth. Granite cleaners also can used for deep cleaning. We do not recommend using abrasive cleaners, chemical solvents, strong detergents, cleaners with bleach or vinegar. Be sure to use trivets, coasters, placemats, or adhesive felt pads to help prevent scratches.

### **FAUX WOOD/MARBLE CARE**

We recommend dusting frequently with a clean, soft, dry, lint-free cloth. Wipe spills immediately with a clean cloth. We do not recommend use aerosol-powered cleaners, polishes that contain silicone, waxes, abrasives, or oil-based. To avoid damaging the surface of the furniture, always use a cutting board when cutting food or other items on the surface. Do not place hot items directly on the surface; always use pads or trivets to prevent damage.

### **METAL FURNITURE CARE**

Because most metals, except aluminum, are subject to rust, metal furniture is usually finished with layers of clear varnish, paint, or a durable powder coating. To clean, use a mild soap solution, scrub, rinse and dry. For outdoor furniture, make sure to drain any water that may accumulate inside the frames after rinsing. After cleaning, apply a coat of quality liquid or paste wax with a lint-free cloth. Use a silicone spray to lubricate swivels and glides on chairs. If metal outdoor furniture is caught during a sudden rainstorm, please make sure to drain any water that may have accumulated inside the frame and dry completely. **Please always cover the furniture when not use, and store properly during inclement weather and the winter/rainy seasons.** For indoor furniture, do not use abrasives products as this may lead to the accidental removal of antique finishes, also to staining or damage to surrounding areas of fabric.

### **FABRIC MATERIALS CARE**

Prevent stains by removing crumbs, dust, dirt, and debris. To remove dirt and debris, vacuum with a dust-brush attachment. Clean spills immediately! For Linen – If the linen item is removable, place the item in a clean sink or tub with cool water and a mild detergent. Gently agitate the linen items, then remove from the soapy water. Rinse with cool water and hang dry. If not removable, then spot clean by dabbing with solution of cool water and a mild detergent on a soft nonabrasive cloth. For Microfiber - If the microfiber item is removable, use machine-wash them in cold water with mild detergent. No fabric softeners as they will clog the open spaces in the microfiber, making the fabric useless. Avoid washing the cotton items because the microfiber will grab on to the lint. If not removable, then spray the area lightly with a water-based solution; using a soft cloth and a blotting motion to remove the stain. Fully air dry.

**Your satisfaction is important to us!**

If any problems or questions, please contact us at

**service@alphamarts.com**

or call our after sale support hotline 1-877-606-2818

Monday-Sunday PST 09:00AM--18:00PM

**Please mention complete Order ID & model/SKU number.**

---

**Thank you for purchasing our product !**