

TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING




EASY --- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 23-02-10

4 / 40



PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

ARM CHAIR



- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.



PARTS



1pc x2



Chair Back





Arm (L&R)



#2) 1pc x2



Chair Seat



#5) 1pc x2



Stretcher



#3) 2pcs x2



Legs





Feet

HARDWARE



(#A) 4pcs x2



(#B) 4pcs x2



#C) 3pcs x2



11pcs x2



Bolt Ø5/16" x 3-1/4"



Bolt Ø5/16" x 2-1/4"



Bolt Ø5/16" x 1-3/4"



Lock Washer Ø5/16"



(#E) 11pcs x2



1pc x2



(#G) 2pcs x2



Flat Washer

Ø5/16"x22mm



Allen Wrench M4



Screw #8 x 50mm

Exploded View

x 2 #1 #2 #3 #6

Align front Leg (#3) to the Chair Seat (#2). Secure using Bolt (#B) with Lock Washer (#D) and Flat Washer (#E).


1

Part #2 x1pc Part #3 x2pc

Hardware #B x4pcs


Hardware #D x4pcs

Hardware (FE) x4pcs



2

Align Chair Seat (#2) to the Chair back (#1) and secure middle holes using Bolt(#C) with washers (#D, #E).




3

Hardware **∉A**) x4pcs

Hardware **#**D x4pcs

Hardware (#E) x4pcs


Secure corners of the Chair Seat (#2) onto the Chair back (#1) by using Bolts (#A) with Washers (#D, #E).



4


Part#5 x1pc


Place the Stretcher (#5) onto the Chair legs. Secure the stretcher by attaching the Feet (#6) to the legs.




Align bottom end of the arms (#4) to the seat (#2), then secure with Bolt (#C) and Washers (#D, #E).

Part#4) x2pcs Hardware#C) x2pcs Hardware#D x2pcs Hardware#E) x2pcs







ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.