

#### **TOOLS REQUIRED**



#### Allen Wrench

(Included)



#### Phillips Screwdriver

(Not Included)



2 - People Recommended

#### **ASSEMBLY RATING**



EASY --- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements?  Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

# PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





#### **Teamwork**

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





#### **Suitable Location**

Assembling near the area of the intended location is highly recommended.





#### **Sufficient Space**

Make sure you have enough space to move around during the assembly.





#### **Avoid Scratches**

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





#### **Flat Surface**

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

## ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

## **TABLE**



- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.




#### **PARTS**





Table Top

4pcs



Leg

#### **HARDWARE**



8pcs



8pcs



8pcs



1pc










Bolt Ø5/16" x 2-3/8"

Lock Washer 5/16"

Flat Washer 5/16" x19mm

Allen Wrench 4mm


## Exploded View




1

Part (1) x1pc Part (2) x4pcs Align Legs (#2) to the Table Top (#1). Secure using Bolts (#A) with washers (#B, #C).

Hardware#A x8pcs Hardware#B x8pcs Hardware#C x8pcs




2



## **PUB CHAIR**



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



#### **PARTS**




1pc x4



1pc x4



2pcs x4



Chair Back



**Cushion Seat** 



Front Leg (L&R)





1pc x4





Side Stretcher(L&R)

Front Stretcher

#### **HARDWARE**



2pcs x4



4pcs x4



4pcs x4



10pcs x4



Bolt



Bolt




Ø1/4" x 1-1/2"

Bolt Ø1/4" x 2-3/8"



6pcs x4







1pc x4







Flat Washer Ø1/4" x19mm



 $\leftarrow$ 



## Exploded View




1

Part (11) x1pc Part (12) x1pc Hardware (14) x2pcs

Hardware#D x2pcs

Hardware#E x2pcs

Align Cushion Seat (#2) to the Chair Back (#1). Secure center using Bolts (#A) with washers (#D,E).




2

Hardware (C) x4pcs

Hardware#D x4pcs

Hardware#E x4pcs

Secure the corners of the Cushion Seat (#2) to the Chair back (#1) using bolts (#C) with washers (#D,E).



Part #3 x2pcs

Part #4 x2pcs


Part #5 x1pc


Hardware#B x4pcs

Hardware (#D) x4pcs

Hardware (#E) x4pcs

Align the Side stretcher (#4) and Front Stretcher (#5) to the Chair Back (#1) and Front Legs (#3). Secure Front legs onto the Cushion Seat (#2) using bolts (#B) with washers (#D,E).





#### **ASSEMBLY** COMPLETED

Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

#### Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

#### Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.