


CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List




HW1x20 Ø 6 x 35 mm	HW2x20 Ø 15 mm	HW3x43 Ø 8 x 30 mm	HW4x4 M 7 x 50 mm	HW5x1 L 4	HW6x8 M 6.4 x 14 mm
HW7x8 Ø 5 x 15 mm	HW8x14 M 3.5 x 15.5 mm	HW9x14 9 x 14 x 10 mm	HW10x4 9 x 14 x 10 mm	HW11x1 L 4	HW12x9 M 6.4 x 25 mm
HW13x4 M 3.5 x 13 mm	HW14x2 Ø 15 mm	HW15x4 Ø 5 x 20 mm	HW16x2 M 3.5 x 25 mm	HW17x2 M 3.5 x 25 mm	HW18x4 M 3.5 x 25 mm
HW19x6 Ø 15 mm					

 **SAFAVIEH**
FURNITURE

Model# MED9605

Product Dimensions: 54.8" W x 15.4" D x 24.2" H



 **WARNING :**
WEIGHT CAPACITY: 57 LBS.
DO NOT STAND ON TV STAND

Part List & HW for Multi-Box Items

Piece	Description	Qty	Carton Call
A	Top Board	1	1 of 2
B	Bottom Board	1	1 of 2
C	Side Board Left	1	2 of 2
D	Side Board Right	1	2 of 2
E	Centre Board Left	1	2 of 2
F	Centre Board Right	1	2 of 2
G	Adjustable Shelf	2	1 of 2
H	Fixed Shelf	1	1 of 2
I	Front Skirt 1	1	1 of 2
J	Front Skirt 2	1	1 of 2
K	Bottom Skirt 1	1	1 of 2
L	Bottom Skirt 2	1	1 of 2
M	Support Board	1	1 of 2
N	Frame Door Left	1	2 of 2
O	Frame Door Right	1	2 of 2
P	Back Board 1	2	2 of 2
Q	Back Board 2	2	1 of 2

Piece	Description	Qty	Carton Call
HW1	Cambolt	20	2 of 2
HW2	CamLock	20	2 of 2
HW3	Dowel Big	43	2 of 2
HW4	Screw M 7 x 50 mm	4	2 of 2
HW5	Allen Key	1	2 of 2
HW6	Screw M 6.4 x 14 mm	8	2 of 2
HW7	Shelf Pin	8	2 of 2
HW8	Screw M 3.5 x 15.5 mm	14	2 of 2
HW9	Wedge	14	2 of 2
HW10	Barn Sliding	4	2 of 2
HW11	Aluminium Plate	1	1 of 2
HW12	Screw M 6.4 x 25 mm	9	2 of 2
HW13	Screw M 3.5 x 13 mm	4	2 of 2
HW14	Sliding Plate	2	2 of 2
HW15	Dowel Small	4	2 of 2
HW16	Stopper	2	2 of 2
HW17	Handle	2	2 of 2
HW18	Screw M 3.5 x 25 mm	4	2 of 2
HW19	Screw Cup	6	2 of 2


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 60 minutes.


1




2











3









4





9**10****11****12**

13**14****15****16**

17**18**