CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wooden furniture from standing water. Dust regularly with small brush or vacuum Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.



NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Weight Capacity: 300 Ibs

Warning: Do not stand on chair

Warning: Do not over torque bolts / screws







Part List and Hardware List

Tart Elot and Harawaro Elot			
PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Seat frame		1X
В	Leg frame		2X
С	Cushion		1X
D	Bolt	M6X30	8X
E	Allen key	4 mm	2X

Model# PAT7084

Product Dimensions:22.8" W x 74.4" D x 34.6" H



PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.

Tools Required for Assembly (included): Allen Key


1

D

D

E D

2



Step 1

Attached Seat frame (A) to Leg frame (B). Using Screw (D) tighten with Allen key (E)

Step 2


Lock or unlock to adjust the seat frame accordingly

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 30 minutes.

Tools Required for Assembly (included): Allen Key



Step 3

Attached Cushion (C) to the Seat frame (A)

Step 5

Caution: This Chair can only be used on a flat, level surface