

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.




Remove wooden furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Top Table		1X
B	Frame Leg		4X
C	Bolt	 M6x50	8X
D	Washer	 M6.5/20X2	8X
E	Allen key	 LG4	1X

 **SAFAVIEH**
O U T D O O R

Weight Capacity : 600 lbs


Warning : Do not stand on chair

Warning : Do not over torque bolts / screws



Model# PAT7066

Product Dimensions: 47.24" W x 23.62" D x 17.71" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1



Step 1

Attach Frame Leg (B) to Top table (A) ,use Bolt (C) Washer (D) and tighten with allen key (E).