

CARE AND MAINTENANCE

Store outdoor furniture indoors or cover well when not in use.

Remove wicker furniture from standing water. Dust regularly with small brush or vacuum

Spills should be taken care of immediately before they harden or stain with a slightly dampened sponge.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

 **SAFAVIEH**
O U T D O O R







Weight Capacity: 275 lbs

Warning : Do not stand on chair

Warning : Do not over torque bolts/ screws




Part List and Hardware List

| PIECE | DESCRIPTION | PICTURE | QUANTITY |
|-------|----------------------------------|---|----------|
| E | Seat Frame |  | 1X |
| B | Leg |  | 4X |
| F | Cushion Back |  | 1X |
| G | Cushion Seat |  | 1X |
| HW1 | Socket screws 6 x 0.5 x 15 mm |  | 16X |
| HW2 | Allen key |  | 1X |

Model# PAT7517

Product Dimensions: 25.59" W x 27.17" D x 28.74" H




PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

1



2



Step 1

Attach Leg (B) to Seat Frame (E). Use Bolt (HW1) tighten with Allen Key (HW2).

Step 2

Like step 1 using Leg (B) is inserted into the Seat Frame (E). Use Bolt (HW1) tighten with Allen Key (HW2).


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.


Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key

3



4



Step 3
Put Back Cushion (F) and Seat Cushion (G) on the Chair.
The Chair is ready to be used.

Step 4
Caution: This Chair can only be used on a flat, level surface