TOOLS REQUIRED



Allen Wrench

(Included)



(Not Included)



3 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

FULL BED



- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.




PARTS





Headboard






Legs





Drawer Front Panel



Drawer Bottom Panel Big Support

#2)x 1pc



Footboard






Center Rail 1930mm






Drawer Back Panel






Drawer Bottom Panel Small Support



#3)x 2pcs





Side Rail





Bed Slat Support 265x30x30mm






Drawer Side Panel




Bed Slat 1397x45x18 mm





Drawer Bottom Panel

HARDWARE PACK IN FOOTBOARD





JCBC M6x40mm

(#B)x 1pc



Allen Wrench M4 x 65mm



#C) x 1pc

Allen Wrench

M5 x 70mm



#D) x 29pcs




CSK Screw 32mm

x 8pcs



CSK Screw 50mm








Adjuster

HARDWARE PACK IN DRAWER

(#G) x 24pcs













CSK Screw 16mm

CSK Screw 32mm

CSK Screw 50mm



(#K) x 24pcs



Power Nail 6/8

x 2pcs



Metal Stopper

Carton	Designation	Part		Hardware	
	Headboard	#1			
	Footboard	#2			#A x 2pcs #B x 1pc #C x 1pc #D x 29pcs #E x 8pcs #F x 2pcs
	Side Rail	#3			
	Legs	#4	•		
	Center Rail	#5			
	Bed Slat Support	#6			

Carton	Designation	Part		Hardware	
	Drawer Front Panel	#8			
	Drawer Back Panel	#9			
	Drawer Side Panel	#10	L R	%	#G x 24pcs #H x 16pcs
	Drawer Bottom Panel	#11			#I x 8pcs #J x 6pcs #K x 24pcs
	Drawer Bottom Panel Big Support	#12			#IC X 24pcs #L x 2pcs
	Drawer Bottom Panel Small Support	#13			
	Bed Slat	#7			


Align and secure the legs (#4) onto the headboard (#1) and the footboard (#2) using CSK screws (#E).


Part #2 x1pc
Part #4 x4pcs
Hardware #E x8pcs

#2

#1


FRONT VIEW






Please keep the adjuster around 5 to 8 mm distant away from the floor.


4







6


Part #11 x1pc





8





ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.