

EC1159B

ASSEMBLY & INSTALLATION INSTRUCTIONS

Components List

Item	Description	Quantity	Item	Description	Quantity
A	Wire Connector	3	D	Short Metal Stem	5
B	Mounting Bracket	1	E	Shade	1
C	Canopy	1	F	Bulb (Not Included)	1

Hardware List

Item	Description	Quantity	Item	Description	Quantity
a	Canopy Mounting Screws	2	b	Barrel Knobs	2

WARNING


TO AVOID THE RISK OF ELECTRICAL SHOCK, BE SURE TO TURN OFF MAIN POWER PRIOR TO INSTALLATION.

CAUTION

Refer to the wattage caution label located near the socket for maximum rated wattage. Do not exceed maximum wattage.

ASSEMBLY & INSTALLATION

1. Carefully unpack fixture from the carton. Take the parts out of package and lay all the fixture components in a clean and flat surface.
2. Determine the number of hanging stems needed in relation to your desired hanging height. Connect Short Metal Stems (D) onto the Shade (E). Rotate and install the Canopy (C) onto the top of the last Short Metal Stem (D).
3. Attach Canopy Mounting Screws (a) into the Mounting Bracket, facing downward. Install the Mounting Bracket (B) to ceiling junction box by using appropriately sized screws (not included).
4. Connect the GROUND WIRE from the fixture and canopy to junction box, secure the electrical connections using the Wire Connector (A). Connect the NEUTRAL (OR WHITE) WIRE from the fixture to NEUTRAL WIRE from power supply with the Wire Connector (A). Connect the HOT (OR BLACK) WIRE from fixture to HOT WIRE from power supply with the Wire Connector (A).
5. Attach the Canopy (C) by inserting its two holes onto the protruding screws from the Mounting Bracket (B) then tighten using Barrel Knobs (b), secure tightly in place.
6. Screw Bulb (not included) (F) into the lamp socket and make sure not to exceed the maximum wattage listed on label.



Note: (1). The above diagram illustrates the installation of your new light fixture. This is a representative drawing and may not match the style of your light fixture.