




# DINING CHAIR

## ASSEMBLY INSTRUCTIONS

### PARTS PACKING CONFIGURATIONS


A. CHAIR BACK 1 PC  
B. SEAT CUSHION 1 PC  
C. CHAIR LEG 2 PCS




#### HARDWARE ENCLOSED IN CARTON

No	Description	Photo	Quantity
1	ALLEN BOLT (5/16 x 2-1/4)		4PCS
2	ALLEN BOLT (5/16 x 3)		4PCS
3	ALLEN BOLT (5/16 x 1-3/4)		1PC
4	LOCK WASHER (5/16)		9PCS
5	FLAT WASHER (5/16)		9PCS
6	ALLEN KEY		1PC

#### DINING CHAIR FULLY ASSEMBLED




#### STEP 1:




DO NOT TIGHTEN BOLTS COMPLETELY

#### STEP 2:



DO NOT TIGHTEN BOLTS COMPLETELY


#### STEP 3:



DO NOT TIGHTEN BOLTS COMPLETELY

#### STEP 4:

ON A FLAT, LEVEL SURFACE PLACE THE CHAIR UPRIGHT. WHEN CHAIR IS LEVELED, PLEASE TIGHTEN ALL ASSEMBLY BOLTS WITH PROVIDED ALLEN KEY.



FULLY ASSEMBLED