






CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly on this item.
- * This item should be assembled on a soft surface to prevent scratching/dirty the surface during assembly.
- * This item may require periodic tightening.


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Top		1X
B	Back Panel		1X
C	Front Cover		1X
D	Left Panel		1X
E	Right Panel		2X












ITEM NO.:ETG2101


Item Dimension:W20 x D12.60 x H68.10”



Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
F	Shelf Top		1X
G	Shelf board		1X
H	Shelf board		1X
I	Shelf board		1X
J	Shelf board		1X
K	Base		1X
HW1	Cam Bolt		48X
HW2	Cam Lock		48X
HW3	Hook		2X


Part List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY
HW4	Phillips Screw (M3x15mm)		4X

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.


1



HW1 x6	
-----------	---

2




HW2 x2	
-----------	---

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

3



HW1 x4	
-----------	--

4




HW1 x12	
------------	--

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

5



HW1 x20	
------------	--

6




HW1 x12	
------------	--

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.


EstimatedAssemblyTime: 30 minutes.

7



HW2 x6	
-----------	--

8




HW3 x2	
HW4 x4	

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

9



HW2 x4	
-----------	--

10




HW2 x10	
------------	--

PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

11



HW1 x10	
------------	--

12




HW2 x6	
-----------	--


PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list. If any part is missing or damaged, do not attempt to assemble the product.
EstimatedAssemblyTime: 30 minutes.

13



14



HW2 x4	
-----------	--