
TOOLS REQUIRED



Allen Wrench

(Included)



Phillips Screwdriver

(Not Included)



2 - People Recommended

ASSEMBLY RATING



EASY → DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.

VERSION # 22-02-11



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.




After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

WRITING DESK WITH CHAIR



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.


















Table Leg Frame - Left (CL)




1pc



Table Leg Frame - Right (CR)





Cross Bar

PARTS - CHAIR

1pc





2pcs



Chair Back

Cushion Seat

Chair Front Leg

HARDWARE - TABLE

#A) 12pcs





















<mmmmc</pre>







JCBC Bolt M6 x 40mm M6 SPRING **WASHER**

M6 FLAT **WASHER** Wood Dowel M8 x 35mm

CB Screw M4 x 38mm Handle

Truss Screw M4 x 30mm

M4 Allen Wrench

HARDWARE - CHAIR

#I) 2pcs



#K) 10pcs

(#L) 10pcs

(#M) 1pc

#N 4pcs



JCBC Bolt M6 x 40mm

JCBC Bolt M6 x 80mm M6 SPRING **WASHER**

M6 FLAT **WASHER** M4 Allen Wrench

JCBC Bolt M6 x 60mm

1

Part (#1) x 1pc

Part (#2) x 1pc


Part (#3) x 1pc

Hardware (#A) x 12pcs

Hardware (#B) x 12pcs

Hardware (#C) x 12pcs

Align Table leg frame (#2 and #3) to the Table top (#1). Secure using Bolts (#A) with Washers (#B and #C).




2

Part (#4) x 1pc

Hardware (#D) x 2pcs

Hardware (#E) x 2pcs

Align and attach Crossbar (#4) to the Table Leg Frame (#2 and #3). Secure using Wood Dowel (#D) and Screw (#E).




3

Hardware (#F) x 1pc

Hardware (#G)x 1pc

Align Handle (#F) and attach using Screw (#G).



4

Part (#5) x 1pc

Part (#6) x 1pc


Hardware(#I)x 2pcs

Hardware (#J)x 4pcs

Hardware (#K) x 6pcs

Hardware (#L) x 6pcs

Align Chair back (#5) to Cushion Seat (#6). Secure using Bolts (#I and #J) with Washers (#K and L).



5


Part(#7)x 2pcs

Hardware (#N) x 4pcs

Hardware (#K) x 4pcs

Hardware (#L) x 4pcs

Align Chair Front Leg (#7) to Cushion Seat (#6). Secure using Bolts (#I) with Washers (#K and L).



6



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all boits and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.