



Liberty Furniture
INDUSTRIES, INC





LIBERTY FURNITURE








ASSEMBLY INSTRUCTION

ITEM#: 779/879/979 - HO121


DESCRIPTION : RIGHT RETURN

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small Hardware which may have come loose inside the carton during shipment. Identify and count all Hardware and compare with the Hardware List Below.

Parts List			
No.	Description		Qty.
①	Right Return Top		1 Pc
②	Front Leg		2 Pcs
③	Side Leg		1 Pc
④	Shelf		2 Pcs

Assembly Hardware Pack			
⑤			
No.	Description	Hardware	Qty.
A	JCBC Screw Ø5/16" x 57mm		6 Pcs
B	Spring Washer Ø5/16"		10 Pcs
C	Flat Washer Ø5/16" x 19mm		10 Pcs
D	Allen Key M4		1 Pc
E	Shelf Pin		10 Pcs
F	Screw M3.5 x 12mm		10 Pcs
G	JCBC Screw Ø5/16" x 35mm		4 Pcs

NOTE: Do not fully tighten Bolts until the assembly is completed.





Liberty Furniture
INDUSTRIES, INC


LIBERTY FURNITURE

ASSEMBLY INSTRUCTION

ITEM#: 779/879/979 - HO121

DESCRIPTION : RIGHT RETURN

ASSEMBLY RIGHT RETURN TO WRITING DESK



DRAWER REMOVAL GUIDANCE

