


ITEM NO: C8741D DINING TABLE

NO	QTY	DRAWING	DESCRIPTION
A	1PC		TABLE TOP
B	4PCS		LEG
C	16PCS		FLAT WASHER
D	16PCS		1/4*12mm
E	1PC		4MM/ALLENKEY

Note:Pls do not tighten all bolts until the chair is assembled completely.Once assembled,tighten all bolts before attaching the chair.

Note: Pls ne pas serrer tous les boulons jusqu'à ce que les selles est completely.Once assemblé assemblé, serrer tous boulons avant de fixer les selles.

Step1



Step2

