PARTLIST							
		2		3		5	à
HEADBOARD CUSHION	x1	FOOTBOARD CUSHION	x1	FOOTBOARD LEG	x2	SIDE RAIL	x2
6		7		8		9	
SIDE RAIL	x2	SIDE RAIL LEG	x2	SLAT	x12	SOCKET	x24
10				12		13	
SUPPORT RAIL	x2	WING (R)	<b>x</b> 1	WING (L)	x1	WING SUPPORT (R)	x1
14		15		24			
WING SUPPORT (L)	x1	SIDE RAIL COVER	x2	VELCRO TAPE	x2		

<sup>\*</sup>All parts needed are shown in above picture. Numbers only indicate the specific parts for easy assembly.

ASSEMBLY INSTRUCTION												
HARDWARE												
A		В		С		D		Е				
JCBB SCREW M8 x 70MM	x4	WOOD DOWEL M10 x 30MM	x4	JCBC SCREW M6 x 15MM	x22	JCBC SCREW M6 x 35MM	x8	JCBC SCREW M6 x 50MM x2				
F		G		Н		I		J T				
SPRING WASHER M6 x 12MM	x10	FLAT WASHER M6 x 19MM	x10	SPRING WASHER M8 x 13MM	x4	FLAT WASHER M8 x 22MM	x4	L - KEY M4 x 100MM x1				
L - KEY M5 x 65MM	) x1											







