

ASSEMBLY INSTRUCTION FOR ITEM C8361QPLS

We believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Please contact us first by emailing service@casepiece.com

Have these ready when you email:

- **Item Number**
- **PO #**
- **Purchaser Name**
- **Proof of Purchase**
- **Description of the problem and/or the Part Number needed**

Replacements for missing or damaged parts or hardware are normally shipped within 3 to business days and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here. This warranty is for manufacturing defects only and does not cover damages as a result of misuse.








1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.
2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.
3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.

We appreciate your business!

ASSEMBLY INSTRUCTION

ITEM : C8361QPLS

PARTLIST




1  HEADBOARD CUSHION x1	2  HEADBOARD LEG x2	3  PLUG x1	4  SLAT x8	5  SIDE RAIL x2
6  SIDE RAIL x2	7  FOOTBOARD x1	8  SIDE RAIL LEG x2	9  SLAT WITH NUT x4	13  DRAWER FRONT PANEL x1
14  DRAWER BACK PANEL x1	15  DRAWER SIDE PANEL x2	16  DRAWER SUPPORT x3	17  DRAWER PANEL x1	18  CASTOR x6
19  SUPPORT RAIL x2	21  SOCKET x24	25  CENTER SUPPORT (SHORT) x1	26  CENTER SUPPORT (LONG) x1	27  SUPPORT LEG WITH HANGER BOLT x3

*All parts needed are shown in above picture.
Numbers only indicate the specific parts for easy assembly.

Please contact service@casepiece.com for assistance

ASSEMBLY INSTRUCTION

HARDWARE

A  JCBB SCREW M8 x 35MM x4	B  SPRING WASHER M8 x 13MM x4	C  FLAT WASHER M8 x 22MM x4	D  JCBC SCREW M6 x 15MM x8
E  JCBC SCREW M6 x 20MM x8	F  JCBC SCREW M6 x 35MM x4	G  SPRING WASHER M6 x 12MM x4	H  FLAT WASHER M6 x 19MM x4
I  CSK C/B SCREW M4 x 32MM x1	J  WOOD DOWEL M6 x 30MM x20	K  MINIFIX CAM LOCK x10	L  MINIFIX BOLT x10
M  CSK C/B SCREW M4 x 16MM x24	N  L - KEY M5 x 65MM x1	O  L - KEY M4 x 100MM x1	P  SUPPORT LEG ADJUSTABLE FEET x3

STEP 1

Open zipper to get all other parts.

REMARK : Headboard leg with label facing backward


STEP 2

The diagram illustrates the second step of the assembly process. It shows two long grey beams labeled '5' and two shorter grey beams labeled '6'. A circular inset provides a detailed view of the assembly. In this inset, a grey plate labeled '8' is being secured to the beams. A red curved arrow indicates the direction of rotation for a screwdriver. The inset also shows a grey plate labeled '5' and a grey plate labeled '6'. A red curved arrow indicates the direction of rotation for a screwdriver. The inset also shows a grey plate labeled '5' and a grey plate labeled '6'.


This diagram illustrates the assembly of a bed frame. The main view shows the headboard, footboard, and side rails. Numbered callouts indicate the following components: 1 (Headboard), 2 (Headboard-to-rail connector), 3 (Side rail), 4 (Footboard-to-rail connector), 5 (Footboard), 6 (Side rail), and 7 (Footboard-to-rail connector). An inset provides a detailed view of the headboard connection, showing a bolt (E) and a washer (O) being used to secure the headboard to the side rail.

ASSEMBLY INSTRUCTION


STEP 5




STEP 6



STEP 7




STEP 8




ASSEMBLY INSTRUCTION


STEP 9




STEP 10



STEP 11




STEP 12




ASSEMBLY INSTRUCTION


STEP 13




STEP 14



STEP 15




STEP 16




ASSEMBLY INSTRUCTION

STEP 17



STEP 18

REMARK : Touch the sensor to turn on the light and adjust the level of brightness.



ASSEMBLY
COMPLETED