

ASSEMBLY INSTRUCTION FOR ITEM C8368FBB

We believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Please contact us first by emailing service@casepiece.com

Have these ready when you email:

- **Item Number**
- **PO #**
- **Purchaser Name**
- **Proof of Purchase**
- **Description of the problem and/or the Part Number needed**

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 business days and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

90-Day Limited Warranty Statement for Manufacturing Defects









Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here. This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.
2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.
3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.





We appreciate your business!

ASSEMBLY INSTRUCTION

ITEM : C8368FBB

PARTLIST				
1  HEADBOARD CUSHION x1	2  WING (R) x1	3  WING (L) x1	4  BOOKCASE PANEL WITH FABRIC x1	5  BOOKCASE PANEL (TOP) WITH LED STRIP x1
6  BOOKCASE PANEL (BOTTOM) x1	7  BOOKCASE SIDE PANEL x2	8  BOOKCASE BACK PANEL x1	9  FOOTBOARD x1	10  FOOTBOARD LEG x2
11  SIDE RAIL (L/R) x2	12  SIDE RAIL (L/R) x2	13  SIDE RAIL LEG x2	14  SLAT x4	15  SUPPORT LEG x4
16  PLUG x1				

ASSEMBLY INSTRUCTION

HARDWARE			
A  JCBB SCREW M8 x 20MMx4	B  JCBB SCREW M8 x 50MMx4	C  JCBC SCREW M6 x 25MMx8	D  JCBC SCREW M6 x 35MMx20
E  JCBC SCREW M6 x 100MMx2	F  WOOD DOWEL M10 x 30MMx4	G  CSK C/B SCREW M4 x 32MMx8	H  SPRING WASHER M6 x 12MMx24
I  FLAT WASHER M6 x 19MMx14	J  SPRING WASHER M8 x 13MMx4	K  FLAT WASHER M8 x 22MMx4	L  L - KEY M4 x 100MMx1
M  L - KEY M5 x 65MMx1	N  WOOD DOWEL M8 x 30MMx10	O  NAILx20	P  MINIFIX CAM LOCKx4
Q  MINIFIX BOLTx4	R  SUPPORT LEG ADJUSTABLE FEETx4		

STEP 1

Diagram illustrating Step 1 of the assembly process. Two long, thin rectangular plates (labeled 5 and 6) are shown being attached to a larger base plate. The base plate has a cable connector on one end. A circular inset shows a close-up of the mounting process: a screw is being driven into the base plate using a screwdriver, and a hammer is used to tap the screw into place. The base plate has a cable connector on one end.

Diagram illustrating the installation of the 7mm x 2mm x 0.5mm spacer. The main view shows a grey plate with two circular holes. Two callouts show the spacer being inserted into the holes. A red arrow points down into each hole. A circular inset shows a close-up of the spacer being inserted into a hole. The inset shows the spacer with a 'P' label and a red arrow pointing down. The hole is labeled '7'. A note says "REMARK : ARROW FACING OUTSIDE".

STEP 3

5

7

7

6

Finish Edge

Q

7


REMARK : 4 hole facing outside.

P


Diagram illustrating the final assembly step. A hammer is shown above the structure, indicating the final tapping of the wire. The structure is labeled with a circled '0' and a circled '8'. A red arrow points down towards the structure. The text "Without Edge" is present, indicating the final state of the structure. A small clip is shown attached to the bottom edge of the structure.

ASSEMBLY INSTRUCTION


STEP 5




STEP 6







STEP 7



STEP 8




ASSEMBLY INSTRUCTION




ASSEMBLY INSTRUCTION

STEP 13




STEP 14



STEP 15

REMARK : Touch the sensor to turn on the light and adjust the level of brightness.



ASSEMBLY
COMPLETED