

ASSEMBLY INSTRUCTION FOR ITEM C8378TUB-3X

We believe you will absolutely love your new furniture. Please immediately examine this product carefully. Any request for missing part or damage replacement must be received within 90 days of your receipt of the product. For some reason you want to return the product, please contact us directly before you decide to return your product to the retailer. Our Customer Service team can answer most concerns and can assist you with any questions you may have about your new product.

Please contact us first by emailing service@casepiece.com

Have these ready when you email:

- **Item Number**
- **PO #**
- **Purchaser Name**
- **Proof of Purchase**
- **Description of the problem and/or the Part Number needed**

Replacements for missing or damaged parts or hardware are normally shipped within 3 to 5 days business and we thank you for your patient.

The item must be returned in good condition, in original box, with all original proof of purchase, parts and accessories, within the time frame specified by the retailer it was purchased from.

90-Day Limited Warranty Statement for Manufacturing Defects

Please read this Limited Warranty carefully. To maintain your Warranty, you will need to comply with the conditions stated here. This warranty is for manufacturing defects only and does not cover damages as a result of misuse.

1. Our products sold comply with the description contained in this Warranty. All parts and products are warranted 90-Day from the original date of delivery except: parts and products used for commercial, contract, rental trade, institutional, or any other non-residential purposes; parts and products that have not been maintained in accordance with the care recommendations provided; parts and products damaged resulting from the consumer's improper assembly; or parts and products that are damaged or defective due to normal wear and tear.

2. To exercise rights under this warranty, proper documentation, i.e., photography, purchase order number, manufacturer's bar code label, and or any other pertinent information upon request is required. We reserve the right to repair or replace the product within the warranty period based upon the documentation received as support of a claim for consideration. We will not replace or repair any product if improper maintenance, improper handling, or improper use caused the damage. Any product sold from or modified by a Non-Authorized Dealer, Seller or Consumer will void the Warranty.






3. Cost of packaging and shipping to and from us is not covered by the warranty unless expressly arranged by us. This warranty does not extend to furniture that has been exchanged or replaced by us as settlement of an original claim of defective merchandise. This warranty does not extend to furniture that has been moved from delivery location on original purchase order.

We appreciate your business!

ASSEMBLY INSTRUCTION



ITEM : C8378TUB-3X

PARTLIST

1  HEADBOARD CUSHION x1	2  FOOTBOARD CUSHION x1	3  FOOTBOARD LEG x2	5  SIDE RAIL x2	6  SIDE RAIL x2
7  SIDE RAIL LEG x2	8  SLAT x4	10  HEADBOARD LEG x2	11  SIDE RAIL COVER x2	24  VELCRO TAPE x2

*All parts needed are shown in above picture.
Numbers only indicate the specific parts for easy assembly.

HARDWARE

A  JCBB SCREW M8 x 50MM x4	B  JCBC SCREW M6 x 15MM x22	C  JCBC SCREW M6 x 20MM x8	D  SPRING WASHER M8 x 13MM x4
E  FLAT WASHER M8 x 22MM x4	F  L - KEY M4 x 100MM x1	G  L - KEY M5 x 65MM x1	

Please contact service@casepiece.com for assistance

STEP 1

Open zipper to get all other parts.

STEP 2

STEP 3


This diagram illustrates the third step of the assembly process. It shows a long, light gray side rail (labeled 2) being attached to a corner bracket (labeled 3). The bracket is already mounted to the corner of the table frame. The rail is positioned horizontally, and its end is being aligned with the bracket. Two circular callouts provide detailed views: one shows the rail's end fitting into the bracket's slot, and the other shows the rail being secured with a bolt (labeled B) and a hex key (labeled F). The hex key is shown inserted into the bracket and turned to tighten the bolt. The rail is labeled 2, and the bracket is labeled 3.

STEP 4


Diagram illustrating Step 4: Attaching the headboard. The headboard (10) is shown being pushed into the frame. The side rails (5) and footboard (2) are also labeled. A circular inset shows a close-up of the headboard being pushed into the frame, with callout B pointing to the connection point and callout F pointing to the headboard's top edge. Red arrows indicate the direction of movement.

ASSEMBLY INSTRUCTION


STEP 5



STEP 6



STEP 7



ASSEMBLY
COMPLETED