
TOOLS REQUIRED



Allen Wrench

(Included)





2 - People Recommended

ASSEMBLY RATING



EASY ---- DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



Are you missing anything?	Check out our Quick Tips!
Double-check all parts, hardware and accessories listed are all acccounted for.	We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!
Should we send any replacements? Are there any irregularities or flaws in the parts? We can send replacements!	Prep Time! Please review the assembly instructions and all diagrams prior to assembling.

PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.





Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Suitable Location

Assembling near the area of the intended location is highly recommended.





Sufficient Space

Make sure you have enough space to move around during the assembly.





Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent to prevent scratches and damages.





Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.

ASSEMBLY AND CARE ADVICE




FAILURE TO FOLLOW THE GUIDELINES BELOW MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.



Position each part correctly and insert screws or bolts into their respective holes.



Use the appropriate hand tools or power tools for assembly. Select steps, such as tightening screws and/or bolts, may require hand tools to avoid causing damage during assembly.



Turn clockwise to tighten and only tighten when step is completed or when instructed to do so.



Save the instructions and store any supplied tools for later maintenance.



After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.


CORNER SOFA

CM6474



(Compress)

- · Please keep instructions for future reference.
- · Check the quantity and irregularity of parts and hardware before you start.




PARTS #1)1pc #2)1pc #3)1pc #4)1pc Left expensive bag Right Arm **Loveseat Frame** Right expensive bag **#**6)1pc **#7**1pc **#**8)1pc (#5) 2pcs Midpack Righe Longue Back Loveseat Frame Back Left Arm #9**)**1pc (#12**)** 2pcs #13**)1**pc 1pc #11**)1**pc Left seat bag Right seat bag Middle seat bag Left dorsal shelf LSF Chaise Cover (Compress) (Compress) #16<mark>12pcs</mark> #1**4)**1pc #15)2pcs 1pc 1pc **RSF Chaise Cover** Love Seat Cover Left handbag Right handbag Leg Cloth Sleeve

CORNER SOFA

CM6474



- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.



HARDWARE





Bolt Ø8 x 20mm

#B) 12pcs



Bolt Ø8 x 60mm

#0

36pcs



Flat Washer






Allen Wrench

CM6474 is packed in 3 cases


Carton	Disignation	Part	Hardware
	Right expensive bag	#3	
	Right Arm	#4	
Right chaise	Righe Longue Back	#8	
ragin ondies	Right seat bag	#11	
	RSF Chaise Cover	#14	
	Right handbag	#18	
	Left expensive bag	#2	
	Lift Arm	#6	
Left chaise	Left dorsal shelf	#9	
Left Chaise	Left seat bag	#10	
	LSF Chaise Cover (compress)	#13	
	Left handbag	#17	
	Loveseat Frame	#1	
	Midpack	#5	#Ax 24pcs
Love seat	Loveseat Frame Back	#7	#B x 12pcs
LOVE SEAL	Middle seat bag (compress)	#12	<pre>#C x 36pcs</pre>
	Love seat cover (compress)	#15	#D x 1pc
	Leg	#16	

Remove parts from the hidden compartment located underneath the bottom.



2

Align designated legs to the bottom and secure using Bolts #A with Flat Washer #C as shown in the diagram.





3

I. Insert Right lounge back (#8) to the Right expensive bag (#3) and secure with Bolts (#B) with Flat Washer (#C).


II. Insert Left Dorsel shelf (#9) to the Left Expensive Bag (#2) and secure using Bolts (#B) with Flat Washer (#C).

III. Insert Loveseat Frame Back (#7) to the Loveseat Frame(#1) and secure using Bolts (#B) with Flat washer (#C).





4




Open and expand sponge. Insert into designated cover.


Part #8 x1pc

Part #9 x2pcs

The compressed sponge has swelled up





Put a cloth cover on it.




Put a cloth cover on it.

6







Open and expand sponge. Insert into designated cover.



Place cushions on sofa.





ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.

✓ Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

✓ Lift, don't drag!

To avoid damage to product please always LIFT the product when transporting of adjusting the placement.