


Thank you for your purchase!



Metal C-Stand with Weather Resistant Finish and Offset Base



ASSEMBLY INSTRUCTIONS

Before You Begin:

Please identify all component parts and hardware pieces required before you begin. Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching during assembly.

Caution:

Tighten all components securely before use. Failure to do so may result in personal injury. DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.

Warning:

CHOKING HAZARD - Small Parts. Adult Assembly Required.

DO NOT ALLOW CHILDREN TO CLIMB ON FURNITURE

Serious or fatal injuries can occur from furniture tipping over. You must install Tipping Restraint Hardware (where included) to help prevent the unit from tipping and causing accidental injury, instability, death or damage. The tipping restraint is intended only as a safety measure, it is not a substitute for proper adult supervision. To help prevent furniture from tipping over it must be permanently attached to the wall. Anti-Tip Safety Wall Straps suitable for the unit weight and wall materials (if not included) should be purchased and installed.

Customer Service Email: CustomerExperience@belnick.com | Phone: 866-552-2810
SB-SH1STAND-GG

Have a Question/Concern?

Quality products and first-class customer service are the cornerstone of long-lasting consumer relationships. We strive toward excellence in all we do and want you to be completely satisfied with your purchase.

Please contact our exceptional Customer Experience Agents at the email address or phone number shown below to assist you with any product questions or issues before requesting a return.

We look forward to serving you in a friendly, efficient manner to resolve any issues you may have.

Customer Service Email: CustomerExperience@belnick.com

Customer Service Phone: 866-552-2810

Our Warranty Statement

This warranty covers manufacturing defects associated with your new product. The product is warranted from the original purchase date and to the original purchaser for normal usage, according to the below-referenced specifications and limitations.







- ☐ Non-moving metal parts are warranted for 5 years.
- ☐ Component parts including pneumatic cylinder, control mechanism, base and casters are warranted for 2 years.
- ☐ All other items are warranted for 1 year.






Normal usage means use in compliance with the restrictions and weight limits specified for the product. In the absence of product-specific restrictions and weight limits, normal usage means use for no more than forty hours per week by persons weighing 250 lbs. or less. Coverage terminates if the product is sold or otherwise transferred. Repairs made by parties other than Belnick also void this warranty.

This warranty will not cover: (1) labor, freight, or damage from misuse, abuse, negligence, alteration, assembly, installation, attachments, accident, vandalism, acts of nature or any other event beyond the control of Belnick; (2) tearing, scratching, scuffing, or blemishing of leather or fabric; (3) cosmetic damage that may result from normal usage; (4) damage attributable to use by persons exceeding specified weight limits or commercial use exceeding forty hours per week; or (5) rust or other damage caused by exposure to moisture. The user assumes all risk of injury resulting from use of this product. Liability for incidental or consequential damage is excluded. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.


.....

PARTS

A		1PCS	SPRING
B		4PCS	NUT
C		M8*16 8PCS	HEX SCREWS
D		M10*65 2PCS	SET SCREWS
E		2PCS	NON-ADJUSTABLE WRENCH
F		1PC	ALLEN WRENCH


G		4PCS	LEGS
H		1PC	UPPER SUPPORT POLE
I		1PC	LOWER SUPPORT POLE
J		1PC	BOLT
K		8PCS	GASKET

STEP 1



STEP 1: Attach (4) Legs (Part G) to the lower half of the Support Pole (Part I) using (8) M8*16 Screws (Part C) and (8) Gaskets (Part K). Tighten using Allen Wrench (Part F).

STEP 2



STEP 2: Connect the Upper Support Pole (Part H) to the Lower Support Pole using (2) M10*65 Set Screws (Part D) and (2) Nuts (Part B). Tighten using Allen Wrench (Part F) and Non-Adjustable Wrench (Part E). Attach Spring (Part A) to the Upper Support Pole.