


























# ASSEMBLY INSTRUCTION

## 884 TUFTED FUTON

<b>A</b> Sofa	<b>B</b> Left Arm	<b>C</b> Right Arm	<b>D</b> Left Bottom Frame
			
<b>E</b> 1PC Right Bottom Frame	<b>F</b> 1PC Wheel Frame	<b>G</b> 1PC Middle Leg	<b>H</b> 1PC Rear Leg
			
<b>I</b> 1PC Left Front Leg	<b>J</b> 2PCS Right Front Leg	<b>K</b> 2PCS Wheel	<b>L</b> 2PCS Cover
			
<b>M</b> 1PC Bolt M6 x 6mm	<b>N</b> 1PC Bolt M8 x 16mm	<b>O</b> 4PCS Bolt 1/4" x 19mm	<b>P</b> 2PCS Bolt 5/16" x 24mm
			
<b>Q</b> 8PCS Bolt 5/16" x 55mm	<b>R</b> 6PCS Bolt 5/16" x 25mm	<b>S</b> 8PCS Bolt 1/4" x 32mm	<b>T</b> 2PCS Nut 1/4"
			
2PCS	8PCS	4PCS	4PCS


<b>U</b> Washer Ø20 x Ø8.5 x 2mm	<b>V</b> Washer Ø20 x Ø10.5 x 2mm	<b>W</b> L-Allen Key 4mm	<b>X</b> Wrench 1/4" x 5/16"
			
4PCS	2PCS	1PC	1PC



These pages list all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1

Screw the Rear Leg (H) to the Sofa (A). Attach the Left & Right Front Leg (I & J) to the Sofa (A), insert the Bolt (N), turn the L-Allen Key (W) to tighten them.



2


Attach the Middle Leg (G) to the Sofa (A), insert the Bolt (M), turn the L-Allen Key (W) to tighten them.



3

Attach the Left & Right Bottom Frame (D & E) to the Sofa (A). Insert the Bolt (P) and Washer (U), turn the L-Allen Key (W) to tighten them. Then insert the Bolt (Q) and Washer (V & U), turn the L-Allen Key (W) to tighten them.


NOTE: Do not fully tighten the bolts. Make sure the joints are moving normally.



4


Attach the Wheel (K) to the Wheel Frame (F), insert the Bolt (S) and Nut (T), turn the L-Allen Key (W) and Wrench (X) to tighten them.

NOTE: The bolts and nuts should be installed in the same direction as shown.




5

Attach the Wheel Frame (F) to the Left & Right Bottom Frame (D & E), insert the Bolt (O), turn the L-Allen Key (W) to tighten them.




6

Push the back of Sofa (A) to the highest position. Then move Left & Right Bottom Frame (D & E) and Wheel Frame (F) to the front as shown.




7

Attach the Left & Right Arm (B & C) to Wheel Frame (F), insert the Bolt (R), turn the L-Allen Key (W) to tighten them.




8

Move the Left & Right Arm (B & C) to both sides of the Sofa (A). Then attach the Velcro from Left & Right Arm (B & C) to the Sofa (A) as shown.




9

Attach the Velcro from the Cover (L) to the Left & Right Bottom Frame (D & E).



10

Futon can be made into different styles by moving Left & Right Arm (B & C) and raising or lowering the back of Sofa (A) as shown.



## Cleaning & Care

Treat surfaces with care. Surfaces are resistant to scratches but are not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.