

ASSEMBLY INSTRUCTIONS

MDS - MID CENTURY OPEN SHELVING UNIT




IMPORTANT NOTE:

Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid parts from being scratched.

Before you begin, kindly follow the assembly instructions step by step.

PARTS INCLUDED



WARNING!

IN ORDER TO PREVENT OVER TURNING THIS PRODUCT MUST BE USED WITH THE WALL ATTACHMENT DEVICE PROVIDED



Serious or fatal crushing injuries can occur from furniture tipping over. To help prevent this item of furniture tipping over:

- * Use the wall attachment device provided.
- * Do not let children climb or hang on drawers, doors or shelves.
- * Place the heaviest items in the lower drawers or shelves.
- * Do not place TV's or other heavy objects on top of this product, unless it has specifically designed to support them
- * Never open more than one drawer at a time.

An attachment device is provided with your product, however you will need to source suitable fixings for your wall type. If in doubt, please consult a qualified trades person.

Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.

01:00 Hs




Philips head screwdriver
required for assembly.
(not included)

HARDWARE INCLUDED



A - 7,0 x 70 Bolt
Qty. 16



B - 4,5 x 60 Screw
Qty. 02



C - 4,0 x 25 Screw
Qty. 09



D - 8,0 x 30 Wood Dowel
Qty. 10




E - Allen Key
Qty. 01



The hardware quantities listed above are required for proper assembly.




Insert wood dowels (D)
into crossbars (1,2 and 3).



D		10
Wood Dowel Ø8,0 x 30		




Fix parts (4 and 5), with the crossbars (1, 2 and 3) using the wood dowels.




STEP 3

Attach parts (4 and 5), with the crossbars (1, 2 and 3) using the bolt (A) and allen key (E).




STEP 4




STEP 5

Attach the pieces (4 and 5), with the shelves (6, 7 and 8) using bolt (A) and Allen key (E).




STEP 6

Fix crossbar (3), with the shelf (6) using the screw (B).



STEP 7

Attach the pieces (2), with the shelves (6, 7 and 8) using screw (C).




C



Screw Ø4,0 x 25

09

STEP 8



ATTENTION


CHILD SAFETY

Serious or fatal injuries can occur from furniture tipping over. To prevent the furniture from tipping over we recommend that it is permanently fixed to the wall. Wall anchor and hardware are included with this product. Please make sure hardware is suitable for your walls before installing, as different wall materials may require different types of anchors.

ANCHOR IT AND PROTECT A CHILD


Use of anti-tip kit is required.

Use of a tip-kit only reduce, not eliminate, tip-over.




- * Place heaviest items in the lowest drawers.
- * Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of the product.
- * Never allow children to climb or hang on drawers, doors or shelves.
- * Never open more than one drawer at a time.
- * Do not defeat or remove the drawer interlock system.
- * Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.

(V) - HARDWARE OF WALL ANCHOR INCLUDED



W - Plastic wall bracket
Qty. 02




X - Nylon strap
Qty. 01






Y - Ø3,0 x 30 Screw
Qty. 02




Z - Ø3,5 x 16 Screw
Qty. 02




Install anti-tip kit directly into wall stud or use included drywall anchor.



STEP 2A




STEP 3A



STEP 4A

Tug on the hardware to ensure that the furniture is attached securely to the wall.



Final Assembly