


# **CAUTION**

- Inspect the wire insulation for any cuts, abrasions, or exposed copper that may have resulted during shipping. If there is a defect in the wire, do not attempt installation.
- Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.

# **TOOLS REQUIRED**



# HARDWARE INCLUDED

















Fixture Iron Rack Ball Nuts

s Chain

Canopy

Screw Collar Ring


Mounting Unit

Mounting Screws

Wire Nuts

#### \*PARTS SHOWN MAY DIFFER SLIGHTLY PER LIGHT FIXTURE


#### **EXPLODED PARTS**



# **INSTALLATION**


#### STEP 1

Attach the iron rack onto fixture using ball nuts.




#### STEP 2

Attach the end of the **chain** to the loop



#### STEP 3

Use the **mounting screws** to attach the **mounting unit** to the junction box (not included).




# **Assembly Instructions**

# **INSTALLATION**


#### STEP 4


Pass the **chain** and the branchwires through the **screw collar ring** and **canopy**. Feed the branchwires through the pipe nipple on the **mounting unit** and attach the end of the **chain** to the **mounting unit**.




#### STEP 5

Make the electrical connection from the junction box to the **fixture**. Connect the ground wire to the **mounting unit** using the preinstalled green ground screw. Then, connect the positive, negative and ground wires with the supplied **wire nuts**. Secure with electrical tape





**STEP 6**Secure the canopy to the mounting unit with the screw collar ring.



STEP 7
Install bulbs (not included)

