









Assembly Instructions

Parts List			
A		B	
1PC		1PC	
D		F	
1PC		1PC	
E		G	
1PC		4PCS	
H		J	
8PCS		1PC	
I		K	
1PC		1PC	


Step1. Back Cushion (E/F) , Backrest (B) , Legs (G/F) And Hardware(H/I/K) Under The Seat.




Step2.





Step3.








Step4.




Step5.




Assembly Instructions

Parts List					
A 			B 		
1PC			1PC		
C 	D 	E 		F 	
1PC	1PC	1PC		1PC	
G 		H 		I 	
4PCS		8PCS		1PC	


Step1. Back Cushion (E/F) , Backrest (B) , Legs (G) And Hardware(H/I) Under The Seat.




Step2.



Step3.



Step4.



Step5.

