









Assembly Instructions

Parts List			
A		B	
1PC		1PC	
D		E	
1PC		1PC	
F		G	
1PC		4PCS	
H		I	
8PCS		1PC	
J		K	
1PC		1PC	


Step1. Back Cushion (E/F) , Backrest (B) , Legs (G/F) And Hardware(H/I/K) Under The Seat.




Step2.





Step3.








Step4.



Step5.



Assembly Instructions

Parts List			
A 		B 	
1PC		1PC	
C 	D 	E 	F 
1PC	1PC	1PC	1PC
G 	H 	I 	
4PCS	8PCS	1PC	

Step1. Back Cushion (E/F) 、Backrest (B) 、 Legs (G) And Hardware(H/I) Under The Seat.

