

ASSEMBLY INSTRUCTIONS

HM - HAMPTON DOUBLE DRESSER









IMPORTANT NOTE:

- * Read and observe carefully all the assembly instructions before beginning assembly.
- * The assembly of the product must be done on a clean and flat surface. We suggest to use the packaging to cover the floor to avoid damages.
- * The screws must be tightened periodically.
- * Avoid contact with sharp objects.
- * Avoid banging pieces together.

PARTS INCLUDED















Please confirm all parts available before assembly.




Tools (not included)				
 01:10 Min Approximately	 02 Persons	 Clean surface	 Philips key	 Hammer

HARDWARE INCLUDED

Please confirm all hardware available before assembly.

Ref.		Qty.	Qty. SPARE
A	 Ø4,0 x 35 mm	75	+ 02
B	 M4 x 25 mm	12	
C	 Ø6 x 10 mm	48	+ 02
D	 Nail	48	+ 04
E	 Ø10 x 40 mm	32	+ 02
F	 Ø8 x 30 mm	24	+ 02
G		06	
H		01	
I	 330 mm Left	06	
J	 330 mm Right	06	
K	 330 mm Left	06	
L	 330 mm Right	06	
M	 Knob	06	
V	 Anti-tip kit	01	

STEP 1




WARNING


Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:




- Install tip-over restraint provided.
- Place heaviest items in the lowest drawers.
- Do not set TV's or other heavy objects on top of this product, unless the product is specifically designed to accommodate them.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time. (CR)
- Do not defeat or remove the drawer interlock system.

Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over. This is a permanent label. Do not remove.


E		32	F		24	H		01
		Ø10 x 40 mm			Ø8 x 30 mm			


STEP 2




			I	 Left 330 mm	06
C	 Ø6 x 10 mm	24	J	 Right 330 mm	06


STEP 3




A	 Ø4,0 x 35 mm	04
---	---	----


STEP 4




A	 Ø4,0 x 35 mm	01
---	---	----


STEP 5




A	 Ø4,0 x 35 mm	02
---	---	----


STEP 6




A	 Ø4,0 x 35 mm	01
---	---	----


STEP 7




A	 Ø4,0 x 35 mm	01
---	---	----


STEP 8




A	 Ø4,0 x 35 mm	07
---	---	----


STEP 9




A	 $\varnothing 4,0 \times 35 \text{ mm}$	07
---	---	----

STEP 10



A	 $\varnothing 4,0 \times 35 \text{ mm}$	04
---	---	----


STEP 11




D		48	G		06
---	---	----	---	---	----


Nail

STEP 12 5x



A		20
---	---	----

STEP 13 1x




WARNING


Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:

- Install tip-over restraint provided.
- Place heaviest items in the lowest drawers.
- Do not set TV's or other heavy objects on top of this product, unless the product is specifically designed to accommodate them.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time. (OR)
- Do not defeat or remove the drawer interlock system.


Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over. This is a permanent label. Do not remove!


A		04
---	--	----


STEP 14 6x




STEP 15 6x




A		24
---	---	----



C		Ø6 x 10 mm	24
K	Left	330 mm	06
L	Right	330 mm	06



B		M4 x 25 mm	12
M		Knob	06



⚠ WARNING

Serious or fatal crushing injuries can occur from furniture tip-over. To help prevent tip-over:


- Install tip-over restraint provided.
- Place heaviest items in the lowest drawers.
- Do not set TV's or other heavy objects on top of this product, unless the product is specifically designed to accommodate them.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time. (OR)
- Do not defeat or remove the drawer interlock system.

Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.
This is a permanent label. Do not remove!

ANCHOR IT AND PROTECT A CHILD


Use of anti-tip kit is required.

Use of a tip-kit only reduce, not eliminate, tip-over.




- * Place heaviest items in the lowest drawers.
- * Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of the product.
- * Never allow children to climb or hang on drawers, doors or shelves.
- * Never open more than one drawer at a time.
- * Do not defeat or remove the drawer interlock system.
- * Use of tip-over restraints may only reduce, but not eliminate, the risk of tip-over.


(V) - HARDWARE OF WALL ANCHOR INCLUDED



W - Plastic wall bracket
Qty. 02



X - Nylon strap
Qty. 01




Y - Ø3,0 x 30 Screw
Qty. 02




Z - Ø3,5 x 16 Screw
Qty. 02

STEP 1A


Install anti-tip kit directly into wall stud or use included drywall anchor.



STEP 2A



STEP 3A



STEP 4A

Tug on the hardware to ensure that the furniture is attached securely to the wall.

