


ASSEMBLY INSTRUCTIONS

DINING TABLE



WF297183

IMPORTANT NOTE:

- PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE TABLE IS FULLY SET-UP.

CARTON CONTENT:

WF297183 :



① x 1



② x 4

TABLE PART LISTS



NO.	DESCRIPTION	SKETCH	QTY
1	TABLE TOP		1 PC
2	TABLE LEG		4 PCS

TABLE HARDWARE LISTS


NO.	DESCRIPTION	SKETCH	QTY
A	HEX COMB 5/16 x 2 1/2"		8 PCS
B	SPRING WASHER 5/16"		8 PCS
C	FLAT WASHER 5/16"		8 PCS
D	SPANNER 12.8		1 PC

ASSEMBLY INSTRUCTIONS

STEP 1




ASSEMBLY
COMPLETE !



ASSEMBLY INSTRUCTIONS

DINING CHAIR




WF297184

IMPORTANT NOTE:


- PLACE ALL PARTS ON A CLEAN AND SMOOTH SURFACE SUCH AS A RUG OR CARPET TO AVOID THE PARTS FROM BEING SCRATCHED.
- BEFORE YOU BEGIN, KINDLY FOLLOW THE ASSEMBLY INSTRUCTIONS STEP BY STEP.
- DO NOT TIGHTEN ALL SCREWS AND BOLTS UNTIL THE CHAIR IS FULLY SET-UP.

CARTON CONTENT:


WF297184 :



1 x 4



2 x 8



3 x 4



4 x 4



CHAIR PART LISTS

NO.	DESCRIPTION	SKETCH	QTY
1	BACK LEG		4 PCS
2	SIDE RAIL		8 PCS
3	FRONT LEG		4 PCS
4	SEAT		4 PCS


CHAIR HARDWARE LISTS

NO.	DESCRIPTION	SKETCH	QTY
A	JCBC BOLT M6 x 45mm		24 PCS
B	SPRING WASHER 1/4"		24 PCS
C	WOOD DOWEL M8 x 30mm		16 PCS
D	ALLEN KEY M4		1 PC
E	C/B SCREW M4 x 30mm		12 PCS


STEP 1



STEP 2



STEP 3



ASSEMBLY
COMPLETE !

