











HKBFNS004-1

INSTALLATION INSTRUCTIONS



FEEDBACK ★ ★ ★ ★ ★

PARTS LIST



PARTS LIST					
NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
A		2	F		4
B		2	G		4
C		2	H		4
D		2	I		4
E		2	J		4

Attention!!! Misaligned Drawers

Over time the rails from the drawers can become loose and drawer parts can become misaligned.

Your dresser drawer, for example, might become very difficult to open and close. It happens. Restoring misaligned drawers to like-new performance is well within your abilities.


The following are detailed instructions to easily fix misaligned drawers with side mounted guides that don't open or shut properly.



Loosen the guide screw and adjust to make the drawer level.



Tighten before reinstalling the drawer

or

















Loosen the guide screw and adjust to make the drawer level.

Tighten before reinstalling the drawer





HARDWARE LIST

NO.	DESCRIPTION	QTY	NO.	DESCRIPTION	QTY
a	 Φ 6*35	24	i	 Φ 3*12	48
b	 Φ 15*10	24	j		8
c	 Φ 6*30	24	k	 Φ 3*16	8
d	 Φ 4*40	8	l	 Φ 4*12	40
e	 Φ 4*35	2	m		8
f	 Φ 4*35	16	n		4
g		4			
h	 Φ 4*12	8			



INSTALLATIONS

STEP 1





X2

STEP 2




X2

STEP 3





X2

STEP 4





X2

STEP 5




X2

STEP 6





X2

STEP 7



X2


STEP 8





X4

STEP 9


nX4 iX24






STEP 10



STEP 11


 eX2

WALL



X2

STEP 12



CAUTION: Always Lift Your Furniture When Moving /Relocating - Do Not Drag. Dragging Can Cause The Legs To Bend/Break.

Thank you very much for purchasing from us.

We have always been trying to provide the best service and reliable products for every customer.

If any accessories are damaged or missing during the installation, you can contact us via the email below and we will replace them for you free of charge.

Many thanks and welcome to our shop again!

NOTE:

If you return the goods yourself, please use UPS or FEDEX, other courier warehouses cannot receive the package.

Contact number: 323-3938260

E-mail: **AnbuyService@outlook.com**

<https://www.amazon.com/anbuy>

Welcome to Anbuy store!

