


ASSEMBLY INSTRUCTIONS COASTER FINE FURNITURE



Fine Furniture for every stage of life

182757 BAR CABINET

REVISION 0: 12/02/2019 REVISION 1: 09/06/2022

PAGE 1 OF 17

COASTERFURNITURE.COM



ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME 80 MINUTES

PARTS IDENTIFICATION

A	TOP PANEL	<		1PC
В	DRAWER TOP PANEL			1PC
С	DRAWER BOTTOM PANEL			1PC
D	DRAWER BACK PANEL	<		1PC
E	DRAWER LEFT PANEL	<		1PC
F	DRAWER RIGHT PANEL	<		1PC
		PAGE 2 OF 17	COASTERFU	RNITURE.COM

ITEM:182757 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



G	DRAWER LEFT DOOR	1PC
Н	DRAWER RIGHT DOOR	1PC
I	DRAWER SHELF PANEL	1PC
J	SHELF GLASS	6PCS
К	DRAWER CROSSBAR	4PCS
L	SIDE CROSSBAR	4PCS
М	BOTTLE RACK	2PCS

ITEM:182757 ASSEMBLY INSTRUCTIONS PARTS IDENTIFICATION



N	SHELF FRAME	6CPS
0	POWER OULET FIXED METAL	1PC
Р	DOOR KNOB	2PCS
Q	GLASS HOLDER	2PCS
R	POWER OUTLET	1PC




HARDWARE IDENTIFICATION


1	PLASTIC MAGENT		1PC	9	SHORT SCREW (ø4 x 12mm)	•	16PCS
2	HINGE	S	4PCS	10	SHORT BOLT (1/4" x 12mm SR)	•	8PCS
3	HINGE INSERT	9	4PCS	11	LONG BOLT (1/4" x 28mm SR)	9	36PCS
4	WOOD DOWEL (8 x 30mm)		10PCS	12	SUCTION CUP (Ø10 x 2mm)	0	24PCS
5	SHELF BOLT	\bigcirc	4PCS	13	CAP (20 x 20mm)		8PCS
6	CAM-LOCK (ø15mm)		4PCS	14	GLUE		1PC
7	CAM-BOLT (38.5mm)	02	4PCS	15	RESTRAINT STRAP		3PCS
8	LONG SCREW (Ø4 x 38mm)	STREET, STREET	6PCS	16	ALLEN WRENCH (4mm)		1PC




STEP 1


Do not tighten until each step is completed or instructed.











































STEP 9



PAGE 14 OF 17


COASTERFURNITURE.COM






Product Size : 1200 X 406 X 1092 H (MM)

Product Size: 47 4" X 16" X 43"





Note: Dimension tolerance ±5%

PAGE 16 OF 17

COASTERFURNITURE.COM

ITEM: 182757



ANTI-TIPPING INSTALLMENT INSTRUCTIONS FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.

This restraint may protect against tipping furniture.

Do not allow children to climb on furniture.


This restraint is not a substitute for proper adult supervision.

Failure to detach this restraint before moving the furniture may result in injury and damage.

This tip restraint must be attached to a wall stud using long screw enclosed.


STEP 1

Attach a bracket securely to the back top rail of the furniture using short screw provided, through the smaller hole.



STEP 2

Locate the other bracket on the wall over a plastic wall stud and two inches below the mounting bracket secured to the back of the furniture. Attach the wall stud using the long screw provided, through the smaller hole.



STEP 3

Place the furniture into position so both mounting brackets are vertically in line. Lace the end of the restraint strap through the larger hole in each mounting bracket. Bring both ends together and slide the flat end through the locking end and draw it through until all slack is removed. Confirm that the strap is securely laced and locked.

